State of New Mexico


Energy, Minerals and Natural Resources Department Form C-103 Revised 5-27-2004 FILE IN TRIPLICATE OIL CONSERVATION DIVISION DISTRICT I WELL API NO. 1220 South St. Francis Dr. 1625 N. French Dr., Hobbs, NM 88240 30-025-29130 Santa Fe, NM 87505 5. Indicate Type of Lease 1301 W. Grand Ave. Artesia, NM 88210 STATE X FEE 6. State Oil & Gas Lease No. DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 87410 7. Lease Name or Unit Agreement Name SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A North Hobbs (G/SA) Unit DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals.) Section 24 1. Type of Well: 8. Well No. 312 Oil Well Gas Well Other TA'd Producer 2. Name of Operator 9. OGRID No. 157984 Occidental Permian Ltd. 3. Address of Operator 10. Pool name or Wildcat Hobbs (G/SA) HCR 1 Box 90 Denver City, TX 79323 4. Well Location Feet From The 10 Feet From The North East NMPM Section 24 Township 18**S** County 11. Elevation (Show whether DF, RKB, RT GR, etc.) 3683' KB Pit or Below-grade Tank Application or Closure Distance from nearest fresh water well Distance from nearest surface water Depth of Ground Water Below-Grade Tank: Volume bbls: Construction Material Pit Liner Thickness 12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PLUG AND ABANDON ALTERING CASING PERFORM REMEDIAL WORK REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. **PLUG & ABANDONMENT** CASING TEST AND CEMENT JOB PULL OR ALTER CASING Multiple Completion OTHER: OTHER: Squeeze, Deepen & Convert to Injector 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion? 1. RUPU & RU. Drilled out CIBPs @4020' & 4040'. Set cement retainer @3878'. 2. Squeeze perfs 3940-4095' w/72 bbl @2500 PSI. 3. Tag cement @3858. Drill out cement from 3858 to 3878'. Drill out cement retainer. 4. Drill cement from 3881-4092'. Tag CIBP @4103'. Drill out CIBP @4103'. 5. Clean out fill to CIBP @4202. Drill out remainder of old CIBP's. 6. Drill out fill to PBTD @4326'. 7. Perforate hole @4204-4210, 4220-4228, 4238-4244, 4252-4260, 4280-4290 (86 holes) w/2 JSPF 8. Pickle tbg w/5 bbl 15% NEFE HCL, 6 setting PPI w/total of 55 bbl NEFE HCL. 9. Run in hole w/7" Uni VI pkr, w/1.875 profile nipple on 122 its of 2-7/8" tbg. Set packer @3893' 10. Circ casing w/150 bbl pkr fluid. Test casing to 600 PSI for 30 min & chart for NMOCD. 11. RDPU & RU. Clean location. RUPU 04/27/06 RDPU 05/16/06 I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be closed according to NMOCD guidelines a general permit or an (attached) alternative OCD-approved plan **SIGNATURE** Administrative Associate DATE 05/24/2006 TYPE OR PRINT NAME E-mail address: TELEPHONE NO Mendy johnson@oxy.com 806-592-6280

For State Use Only

APPROVED BY

CONDITIONS OF APPROVAL FANY:

OC FIELD REPRESENTATIVE II/STAFF MANTADATE



Serial XX 227.06

CAL CLOCKS BY SMITH'S MARROND

PUMP BY SMITH'S MARROND

PUMP