

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - A" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- WATER INJECTION	7. Unit Agreement Name EUMONT HARDY UNIT
2. Name of Operator Conoco Inc.	8. Farm or Lease Name EUMONT HARDY UNIT
3. Address of Operator P. O. Box 460, Hobbs, New Mexico. 88240	9. Well No. 44
4. Location of Well UNIT LETTER 0 3300 FEET FROM THE SOUTH LINE AND 1980 FEET FROM THE EAST LINE, SECTION 6 TOWNSHIP 21 S RANGE 37 E NMPM.	10. Field and Pool, or Wildcat EUMONT YATES 7 RVRS.
15. Elevation (Show whether DF, RT, GR, etc.)	12. County LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER SURFACE WATERFLOW REPAIR <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1506.

RECOMMENDED PROCEDURE:

1. SI well, open the intermediate csg valve, and relieve the 9-5/8" - 7" casing annulus pressure.
2. Connect the intermediate csg to pump truck w/reliable pressure gauge, and connect another gauge to the tubing casing annulus.
3. Make several attempts to pump 10 Bbls fresh water between the intermediate - production casings at 800 psi maximum pressure, and report injection rate and pressure and any pressure increase in the tubing-casing annulus to the area engineer. Proceed within 2 days.
4. If fresh water is pumped between the casings at 800 psi or less, run tracer survey to determine how deep the fresh water will reach behind the production casing. Contact Engineering.

(OVER)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *W. A. Kestner* TITLE Administrative Supervisor DATE 6/28/83

APPROVED BY *Eddie W. [Signature]* TITLE OIL & GAS INSPECTOR DATE JUL 5 1983

CONDITIONS OF APPROVAL, IF ANY:

5. If fresh water could not be pumped between the 9-5/8" and 7" casings at 800 psi or less, install BOP and POOH w/tubing.
 - A. GIH w/5-1/2" casing scraper on workstring, and circulate well clean w/fresh water treated w/2% KCl and 1:1000 Adomall to 3500' and POOH.
 - B. GIH w/5-1/2" csg packer on workstring, set packer @ 2800', load back- side w/TFW, and pressure the tubing-casing annulus w/500 psi. Run intermediate tracer survey at 1000 psi maximum injection pressure. Contact Engineering.
6. Rig up and cement between the surface and the production casings at 1000 psi maximum pressure and 1 BPM if packer is used. If packer is not used, the maximum pressure is 800 psi and the injection rate is not to exceed that of the fresh water rate pumped between the casings prior to cementing.

NOTE: This step only if tracer survey shows water is going past casing shoe.

Cement required to cement to 1373'


Between casings: 0.2009 cu. ft./ft: 275 sacks, plus 20 sacks

Lead-in with 20 sacks Class "C" cement w/18% salt mixed with 6.3 gals. fresh water/sack.

Tail-in with 275 sx. Class "C" cement w/2% CaCl₂ mixed w/6.3 gals. fresh water/sack, and slurry weights 14.8 lbs/gal

Pressure and rate should be recorded during cementing and sent to the Division Office.

7. Displace cement slurry w/fresh water through the wellhead. Do not displace cement in the casings annulus. Close the intermediate valve. SION. Proceed to Step 12 if rig not used.
8. Unseat packer, and POOH w/workstring and packer.
9. RIH w/tubing bull plugged and pressure test every 10 stands to 1500 psi. POOH w/tubing.
10. RIH w/cement lined tubing and AD-1 packer.
11. Circulate packer fluid down annulus, displace casing, set packer, top off casing.
12. Put well on injection and report results to the Division Office.



MORAS OFFICE
O.C.D.
JUL 1 1963
RECEIVED