

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-23611
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Lea DS State
8. Well Number 1
9. OGRID Number 003474
10. Pool name or Wildcat Lea San Andres

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
C. W. Trainer

3. Address of Operator
P. O. Box 754, Midland, Texas 79702

4. Well Location

Unit Letter E: 2086 feet from the North line and 554 feet from the West line
Section 36 Township 19S Range 34E NMPM Lea County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3713'

Pit or Below-grade Tank Application ☐ or Closure ☐ No pit needed.

Pit type Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water

Pit Liner Thickness: mil Below-Grade Tank: Volume bbls; Construction Material

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Procedure to Plug and Abandon.

- 1.) Move in and rig plugging unit.
- 2.) Pull Tubing.
- 3.) Run wireline and free point 5 1/2" casing.
- 4.) Set bridge plug at 5900' K.B.
- 5.) Cut 5 1/2" casing, spot 100' cement plug in and out of 5 1/2" casing stub.
- 6.) Set plug at 3080' K.B.
- 7.) Spot 100' cement plug from 3075' to 2975' across the Yates formation.
- 8.) Pull tubing to 470'.
- 9.) Spot 100' cement plug from 470' - 370' across 13-3/8" casing shoe.
- 10.) Pull tubing to 100' and spot plug to surface.
- 11.) Cut off well head and install P&A marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE Sheryl L. Jonas TITLE Agent DATE 08/16/06

Type or print name Sheryl L. Jonas E-mail address: Sjonas4011@aol.com

Telephone No. (432) 683-5511

For State Use Only

OC FIELD REPRESENTATIVE II/STAFF MANAGER

APPROVED BY: Larry W. Wink TITLE DAUG 17 2006

Conditions of Approval (if any):

THE OIL CONSERVATION DIVISION MUST
BE NOTIFIED 24 HOURS PRIOR TO THE
BEGINNING OF PLUGGING OPERATIONS.