

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. DIV-Dist. 2
1301 W. Grand Avenue
Alamogordo, NM 88210

APPROVED
OMB No. 1004-0135
Expires November 30, 2000

SUNDRY NOTICES AND REPORTS ON WELLS
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

SUBMIT IN TRIPLICATE - Other instructions on reverse side

1. Type of Well
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator
J.R. STEARNS

3a. Address
HC 63 Box 988 CROSSROADS
ALAMOGORDO NM 88214

3b. Phone No. (include area code)
505-369-5015

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
660' FSL + 330 FEL (P)
Sec. 28, T-7-S, R-31-E

5. Lease Serial No.
USA NM 16637

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.

8. Well Name and No.
HAHN FEDERAL "A"

9. API Well No.
2


10. Field and Pool, or Exploratory Area
TOM-TOM (SAN ANDRES)

11. County or Parish, State
CHAVES N.M.

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

| TYPE OF SUBMISSION | TYPE OF ACTION | | | |
|---|---|--|--|---|
| <input type="checkbox"/> Notice of Intent | <input type="checkbox"/> Acidize | <input type="checkbox"/> Deepen | <input type="checkbox"/> Production (Start/Resume) | <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Subsequent Report | <input type="checkbox"/> Alter Casing | <input type="checkbox"/> Fracture Treat | <input type="checkbox"/> Reclamation | <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Final Abandonment Notice | <input type="checkbox"/> Casing Repair | <input type="checkbox"/> New Construction | <input type="checkbox"/> Recomplete | <input type="checkbox"/> Other |
| | <input type="checkbox"/> Change Plans | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Temporarily Abandon | |
| | <input type="checkbox"/> Convert to Injection | <input type="checkbox"/> Plug Back | <input type="checkbox"/> Water Disposal | |

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)



See conditions of approval pg 2.

14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed)

D.G. WILLIAMSON

Title

SAFETY CONSULTANT

Signature

[Signature]

Date

8/4/03

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

[Signature]

DISTRICT SUPERVISOR

OR GENERAL MANAGER

Date AUG 22 2003

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Hahn Federal Number #2
Plugging and Abandonment Procedure

13. MI and RU DDU. COOH and LD Rods. ^{3825'} COOH with Tbg. RU Wireline. GIH with 4-1/2" CIBP and set at ^{35'} 2870'. Dump 30' cement on top of CIBP. GIH with Tbg. Circulate hole with gelled brine. COOH and LD Tbg. ~~GIH with 4-1/2" CIBP and set at 1450'. Dump 30' cement on top of CIBP.~~ Set 60' surface plug. Dig out and cut off casing 3' below ground level. Weld seal plate on top of casing. Set dry hole marker. Clean location and remediate.


Additional Plugs:

- 1) Perf. 4 1/2" @ 2000' + squeeze leave 100' plug from 2000' - 1900' inside 4 1/2".
- 2) perf 4 1/2" @ 1492' + squeeze. leave 100' plug from 1492' - 1392' inside 4 1/2" + TAG.

OPERATOR: STEARNS

WELL: PLAIN Fld #2 LEASE NO.:


LOCATION: 14 / SEC. 28 T-7S R-5E



1442'

PERFS. { 3876'
4014'

4120'



8 5/8" Csg 24 lb. Set @ 1442'

12 1/4" Hole Size

Cemented w/ 600 sx HAH light
& 200 sx Class C.

Calculated Circulated to Surface.

2825' TOC

4 1/2" Csg 9.5 #Lb. Set @ 4120'

7-7/8" Hole Size

Cemented w/ 250 sx Class H

Calculated TOC 2825'