Submit 3 Copies To Appropriate District Office	State of New Mexico	F
District I	Energy, Minerals and Natural Res	Form C-103 May 27, 2004
1625 N. French Dr., Hobbs, NM 88240	Energy, winerars and Natural Xes	WELL API NO.
District II 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVIS	SION 30-041-10050
District III	1220 South St. Francis Dr	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 87505	• STATE FEE STATE Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 8750		6. State Off & Gas Lease No. LC 062178
SUNDRY NOT	ICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name:
DIFFERENT RESERVOIR. USE "APPLIC	ALS TO DRILL OR TO DEEPEN OR PLUG BACK ATION FOR PERMIT" (FORM C-101) FOR SUCH	TO A Milnesand Unit
PROPOSALS.) 1. Type of Well: Oil Well	Gas Well 🗌 Other	8. Well No. 137
2. Name of Operator		9. OGRID Number
Thompson J. Cleo		
3. Address of Operator		10. Pool name or Wildcat
P.O. Box 12577 Odessa T 4. Well Location	x. 79768-2577	Milnesand (San Andres)
	1980 feet from the South lin	ne and 660 feet from the East line
Section 7	Township 8S Range 351	
	11. Elevation (Show whether DR, RKB, RT	
	4250' (DF)	
Pit or Below-grade Tank Applica		
Pit type Depth to Ground Pit Liner Thickness:		er well Distance from nearest surface water
	nil Below-Grade Tank: Volume	
12. Check A	ppropriate Box to Indicate Nature of	Notice, Report or Other Data
NOTICE OF IN	TENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK		
		ENCE DRILLING OPNS. P AND A
PULL OR ALTER CASING		G/CEMENT JOB
OTHER:		
13. Describe proposed or complete	J operations. (Clearly state all pertinent det	ails, and give pertinent dates, including estimated date of Attach wellbore diagram of proposed completion or
recompletion.	CE RULE 1105. FOR MULLIPLE COMPLETIONS	. A Πach Wellbore diagram of proposed completion or
		. Attach wendere diagram of proposed completion of
Proposed Plug and Abandon Ope		. Traini weneore angrain of proposed completion of
Proposed Plug and Abandon Ope	ration	
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/	ration 81. Dump 3 sx cement on top of existing (CIBP.
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plu	ration 81. Dump 3 sx cement on top of existing (2 (2 مارس بر عمام (Tag) مراجع	CIBP. Ris Ris Rizer
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750' Set P	ration 81. Dump 3 sx cement on top of existing (g @ 4025' to 4125'. (Tag) アレムターメーン actor @ 2650! & course 80 course and	CIBP. IT & R (of RIZO)
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750' Set P	ration 81. Dump 3 sx cement on top of existing (g @ 4025' to 4125'. (Tag) アレムターメーン actor @ 2650! & course 80 course and	CIBP. IT & R (of RIZO)
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750' Set P	ration 81. Dump 3 sx cement on top of existing (g @ 4025' to 4125'. (Tag) アレムターメーン actor @ 2650! & course 80 course and	CIBP. IT & R (of RIZO)
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750' Set P	ration 81. Dump 3 sx cement on top of existing (g @ 4025' to 4125'. (Tag) アレムターメーン actor @ 2650! & course 80 course and	CIBP. Ris Rios Rizer
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750' Set P	ration 81. Dump 3 sx cement on top of existing (g @ 4025' to 4125'. (Tag) アレムターメーン actor @ 2650! & course 80 course and	CIBP. <i>IT & R (a) R / 20</i> ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (Tag) . (Tag)
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750' Set P	ration 81. Dump 3 sx cement on top of existing (2 (2 مارس بر عمام (Tag) مراجع	CIBP. <i>IT & R (a) R / 20</i> ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (Tag) <i>IT ag</i> <i>IT a</i>
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ <u>Plug #2: Pump 20 Sx Cement Plug</u> Plug #3: Perforate @ 2750'. Set P. Plug #4: Perforate @ 2250'. Set P. Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker	ration 81. Dump 3 sx cement on top of existing (2 @ 4025' to 4125'. (Tag) مراحم مراحم المراحم acker @ 2650' & squeeze 80 sx cement plu acker @ 2150' & squeeze 80 sx cement plu cker @ 373' & squeeze backside w/150 sx.	CIBP. <i>IT is Quei Theor</i> ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) . (Tag) <i>IT 13</i> <i>IT 13</i> <i>IT 13</i> <i>IT 15</i> <i>IT 16</i> <i>IT </i>
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ <u>Plug #2: Pump 20 Sx Cement Plug</u> Plug #3: Perforate @ 2750'. Set P. Plug #4: Perforate @ 2250'. Set P. Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker	ration 81. Dump 3 sx cement on top of existing (g @ 4025' to 4125'. (Tag) アレムターメーン actor @ 2650!	CIBP. <i>IT is Quei Theor</i> ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) . (Tag) <i>IT 13</i> <i>IT 13</i> <i>IT 13</i> <i>IT 15</i> <i>IT 16</i> <i>IT </i>
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set Pa Plug #4: Perforate @ 2250'. Set Pa Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL	ration 81. Dump 3 sx cement on top of existing (2@ 4025' to 4125'. (Tag) Plag Aor acker @ 2650' & squeeze 80 sx cement plu acker @ 2150' & squeeze 80 sx cement plu cker @ 373' & squeeze backside w/150 sx.	CIBP. 17.# Quin Rusof ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag), 14,1516 17 16 (Tag) (Tag) (Tag) (Tag)
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set P. Plug #4: Perforate @ 2250'. Set P. Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO	ration 81. Dump 3 sx cement on top of existing (2 @ 4025' to 4125'. (Tag) Place of a so acker @ 2650' & squeeze 80 sx cement plu acker @ 2150' & squeeze 80 sx cement plu cker @ 373' & squeeze backside w/150 sx. CONSERVATION DIVISION	CIBP. 77 # & coi 7/12cf ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) . (
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set Pa Plug #4: Perforate @ 2250'. Set Pa Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the info BEGINAN	ration 81. Dump 3 sx cement on top of existing O g @ 4025' to 4125'. (Tag) Plag Nor acker @ 2650' & squeeze 80 sx cement plu acker @ 2150' & squeeze 80 sx cement plu acker @ 373' & squeeze backside w/150 sx. CONSERVATION DIVISION IN the plugation of the plugation of the plugation State of the plugation of the plugation of the plugation of the plugation of the p	CIBP. <i>It is a contract</i> ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (Tag) (Tag) <i>It is a contract</i> <i>It is a contract</i> <i>It</i>
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set Pa Plug #4: Perforate @ 2250'. Set Pa Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the information and has been/will be constructed or closed and	81. Dump 3 sx cement on top of existing O 91. Dump 3 sx cement on top of existing O 92. 4025' to 4125'. (Tag) 402.5' to 4125'. (Tag) 402.5' to 4125'. (Tag) 40.5' A squeeze 80 sx cement pluster 40.5' & squeeze 80 sx cement pluster 40.5' & squeeze 80 sx cement pluster 6. CONSERVATION DIVISION [] 5. CONSERVATION DIVISION [] 6. CONSERVATION DIVISION [] 7. TIFIED 24 HOURS PRIOR TO TO 10. NSALVANCE Completed other cest of may khow for excording to NMOCD guidelines [], a general per second in the other cest of may khow for excording to NMOCD guidelines [], a general per second per seco	CIBP. 77 # & coi 7/12cf ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) . (
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set Pa Plug #4: Perforate @ 2250'. Set Pa Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the info BEGINAN	ration 81. Dump 3 sx cement on top of existing O g @ 4025' to 4125'. (Tag) Plag Nor acker @ 2650' & squeeze 80 sx cement plu acker @ 2150' & squeeze 80 sx cement plu acker @ 373' & squeeze backside w/150 sx. CONSERVATION DIVISION IN the plugation of the plugation of the plugation State of the plugation of the plugation of the plugation of the plugation of the p	CIBP. <i>It is a contract</i> ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (Tag) (Tag) <i>It is a contract</i> <i>It is a contract</i> <i>It</i>
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set P. Plug #4: Perforate @ 2250'. Set P. Plug #5: Perforate @ 473'. Set Par Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the informer States has been/will be constructed or closed and SIGNATURE	ration 81. Dump 3 sx cement on top of existing O 9. 4025' to 4125'. (Tag) 9. 2650' & squeeze 80 sx cement plu acker @ 2650' & squeeze 80 sx cement plu acker @ 2150' & squeeze 80 sx cement plu acker @ 373' & squeeze backside w/150 sx. CONSERVATION DIVISION [] TIFIED 24 HOURS PRIOR TO TO INStructure to the best of mly knowled backstore to NMOCD guidelines [], a general pe	CIBP. R & R & Coi R & Coi ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set Pa Plug #4: Perforate @ 2250'. Set Pa Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the infoBEGIANT has been/will be constructed or closed and SIGNATURE Type or print name Jim Otts	81. Dump 3 sx cement on top of existing O 31. Dump 3 sx cement on top of existing O 32. Additional action of the second state o	CIBP. TREACINE ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (Tag
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set P. Plug #4: Perforate @ 2250'. Set P. Plug #5: Perforate @ 473'. Set Par Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the informer States has been/will be constructed or closed and SIGNATURE	81. Dump 3 sx cement on top of existing O 31. Dump 3 sx cement on top of existing O 32. Additional action of the second state o	CIBP. R & R & Coi R & Coi ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set Pa Plug #4: Perforate @ 2250'. Set Pa Plug #5: Perforate @ 473'. Set Pa Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the information of the set o	81. Dump 3 sx cement on top of existing O 31. Dump 3 sx cement on top of existing O 32. Additional action of the second state o	CIBP. 7.5 & coi 10 = 0 ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (Ta
Proposed Plug and Abandon Ope Plug #1: CIBP set @ 4525' on 1/7/ Plug #2: Pump 20 Sx Cement Plug Plug #3: Perforate @ 2750'. Set P. Plug #4: Perforate @ 2250'. Set P. Plug #5: Perforate @ 473'. Set Par Plug #6:Pump 10 sx surface plug Install dry hole marker THE OIL BE NO I hereby certify that the informed and the has been/will be constructed or closed and SIGNATURE Type or print name Jim Otts For State Use Only	81. Dump 3 sx cement on top of existing O 9 4025' to 4125'. (Tag) acker @ 2650' & squeeze 80 sx cement pluacker @ 2150' & squeeze 80 sx cement plucker @ 373' & squeeze backside w/150 sx. CONSERVATION DIVISION [] TIFIED 24 HOURS PRIOR TO THE Control of the best of may know the best of my know the best	CIBP. TREACINE ug from 2650' to 2750'. (Tag) ug from 2150' to 2250'. (Tag) (Tag

Thompson, J. Cleo

Proposed P&A - Milnesand Unit #137

Milnesand (San Andres) 1980' FSL & 660' FEL, Unit Letter I, Sec 7, Township 8S, Range 35E, Roosevelt County, NM Completed 07/20/1964



Plug #6: 10 sxs @ surface

Plug #5: Perforate @ 473'. Set pkr @ 373' & squeeze backside w/ 150 sx t

Surface String 8-5/8", 24#, set @ 423' Cement w/ 200 sxs, TOC @ surface (Circ.)

Plug #4: Perforste @ 2250'. Set pkr @ 2150' & squeeze 80 sx plug from 2

Plug #3: Perforate @2750'. Set pkr @ 2650' & squeeze 80 sx plug from 26

- TOC @ 3730' (Temp Survey)

Production String 4-1/2", 9.5#, set @ 4718' Cement w/ 350 sxs neat cmt TOC: 3730' (Calculated)

Plug #2: Pump 20 sx cnst plug @ 4025' to 4125' (Tag)

Plug #1: CIBP set @ 4525' on 11/7/81. Dump 3 sxs cement on top of existir

San Andres Perfs: 4626' - 4670'

PBTD: 4525' (CIBP)