Submit 3 copies to Appropriate District Office	State c	f New Mexico		Form C-103	
DISTRICT I 1625 N. French Dr., Hobbs NM 88240	Energy, Minerals and Natural Resources			Revised March 25, 1999 WELL API NO.	
<u>DISTRICT II</u>	OII CONSEE			20225	
1301 W. Grand Avenue, Artesia NM 88210 DISTRICT III	W. Grand Avenue, Artesia NM 88210 OIL CONSERVATION DIVISION 1220 South St. Francis Dr.			5-29335	
1000 Rio Brazos Rd., Aztec NM 87410 Santa Fe, New Mexico 87504-2088			5. Indicate Type of Le	FEE X	
DISTRICT IV			6. State Oil & Gas Le		
1220 S. St. Francis Dr., Santa Fe, NM 8750	5 UNDRY NOTICES AND REPORT				
(DO NOT USE THIS FORM FOR PIDIFFERENT RESERVOIR. USE "A	7. Lease Name or Un	it Agreement Name			
PROPOSALS.) 1. Type of Well:			Shir	Shipp ZI	
Oil Well X Gas Well Other			J	Simple 21	
2. Name of Operator			8. Well No.		
Yates Petroleum Corporation			j.	3	
3. Address of Operator			9. Pool Name or Wild	9. Pool Name or Wildcat	
	5 South 4th Str., Artesia,	NM 88210	Lovingtor	Penn NE	
4. Well Location					
Unit Letter E : 1470	O feet from the North	line and 660	feet from the	West line	
Section 27	Township 16S Range	e 37E NMPM	County	Lea	
10.	Elevation (Show whether DF, R 3786.7' GR	KB, RT, GR, etc.)	To the second se		
11. Check Appropriate B	ox to Indicate Nature of Not	ice. Report, or Other Data			
	INTENTION TO:	•	UENT REPORT OF:		
PERFORM REMEDIAL WORK	PLUG AND ABANDON X	REMEDIAL WORK	ALTERING CASING		
TEMPORARILY ABANDON	CHANGE PLANS			- [
PULL OR ALTER CASING	MULTIPLE	COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JOB	PLUG AND ABANDONMEN	<u> </u>	
OTHER.	COMPLETION				
		OTHER:			
12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date					
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. THE COMMISSION MUST BE NOTIFIED 24					
HOURS PRIOR TO THE BEGINNING OF					
Propose to P&A as follows: PLUGGING OPERATIONS FOR THE C-103					
TO BE APPROVED. 1) MIRU WSU. Install BOP and TOH w/tbg.					
2) Set CIBP @ 10890' w/35' cement on plug.					
3) Circulate hole w/9.5 ppg mud-laden fluid. Spot 100' cement plug 7948-7848'.					
4) Perforate squeeze holes @ 4922'. Set packer @ 4750'. Pump 35 sx plug. Displace to 4800'. — TAG					
		Set packer @ 4150'. Pum	nn 35 sy nlug. Displace	to 4250'TAG	
		Set packer @ 1950'. Pum	np 35 sx plug. Displáce	to 2050' - TAG	
		et packer @ 300'. Pump :			
	ment plug @ surface.	. •		SEL TOO	
	er and clean location.		1 · · · · · · · · · · · · · · · · · · ·	REJULIAS	
			1	HODOS	
				0 -	
Thereby certify that the informa	ation above a true and complete to	the best of my knowledge and beli		. <u></u>	
SIGNATURE SIGNATURE	TITL			9/24/03	
Type or print name Sto	rmi Davis				
Type or print name Sto (This space for State use)		DICTRICT CLIDED TO OB (CT	Telephone No.	505-748-1471	
APPROVED BY	uy W. Wink TITL	DISTRICT SUPERVISOR/GEI	NERAL MANAGER DATE	SEP 2 9 2003	
Conditions of approval, if any:	V				

. ∳. •