

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

FILE IN TRIPLICATE

OIL CONSERVATION DIVISION

DISTRICT I
P O. Box 1980, Hobbs, NM 88240

2040 Pacheco St.
Santa Fe, NM 87505

DISTRICT II
811 S 1st Street, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87410

WELL API NO. 30-025-05441	
5. Indicate Type of Lease FED <input type="checkbox"/> STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>	
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name NORTH HOBBS (G/SA) UNIT	
8. Well No	211
9. Pool name or Wildcat	HOBBS (G/SA)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101 FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other TA'd Producer	
2. Name of Operator Oxy Permian LTD.	
3. Address of Operator HCR 1 Box 90 Denver City, TX 79323	
4. Well Location Unit Letter <u>C</u> : <u>660</u> Feet From The <u>NORTH</u> Line and <u>1980</u> Feet From The <u>WEST</u> Line Section <u>13</u> Township <u>18S</u> Range <u>37E</u> NMPM LEA County	
10 Elevation (Show whether DF, RKB, RT GR, etc) 3690 df	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG & ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)
SEE RULE 1103

1. Notify NMOCD of plugging operations.
 2. Tag PBTD at 4100' (CIBP) and cap with 25 sxs of cmt. Verify TOC.
 3. Spot 25 sxs cmt plug from 1800' across salt top. Verify TOC.
 4. Spot 65 sxs cmt plug from 600' to surface. Verify TOC at surface.
 5. Cut off wellhead and install dry hole maker with labeling.
 6. Clean up location, remove anchors.
- SPOT 100' PLUG F/3080'-2980'

RECEIVED

JAN - 7 2008

HOBBS OCD

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE <u>D. Nelson</u>	TITLE <u>Engineering Advisor</u>	DATE <u>1/7/2008</u>
TYPE OR PRINT NAME <u>D. NELSON</u>	TELEPHONE NO <u>505/397-8200</u>	

(This space for State Use)

APPROVED BY <u>Harry W. Wink</u>	TITLE <u>OC FIELD REPRESENTATIVE II/STAFF/INVESTIG.</u>	DATE <u>JAN 07 2008</u>
CONDITIONS OF APPROVAL IF ANY:		

North Hobbs Unit
Well # 13-211
660 FNL & 1980 FWL (Unt Ltr C)
T-18-S, R-37-E
API # 30-025-05441

