

Submit 3 Copies to Appropriate District Office  
District I  
625 N. French Dr., Hobbs, NM 88240  
District II  
301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
May 27, 2004

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☐ Other WIW ☐

2. Name of Operator

State of New Mexico formerly Pronghorn MGMT

3. Address of Operator

1625 N. French Dr. Hobbs, NM 88240

4. Well Location

Unit Letter F: 2630 feet from the N line and 1340 feet from the W line

Section 21 Township 24S Range 37E NMPM County Lea

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

Pit or Below-grade Tank Application ☐ or Closure ☐

Pit type \_\_\_\_\_ Depth to Groundwater \_\_\_\_\_ Distance from nearest fresh water well \_\_\_\_\_ Distance from nearest surface water \_\_\_\_\_

Pit Liner Thickness: \_\_\_\_\_ mil Below-Grade Tank: Volume \_\_\_\_\_ bbls; Construction Material \_\_\_\_\_

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ P AND A ☐

CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

WD=3696' 7" 20# casing set at 251' w/250 sxs of cement. TOC circulated

2-7/8" 6.5# set at 3696' w/325 sxs of cement. TOC at 2500'

Perfs at 3457'-3658'

TOS at 1125' BOS at 2627'

- 1) Set plug at 3696' 10sxs or approx 400' TAG
- 2) Cut 2-7/8" casing at 2400' and pull
- 3) Set plug at 2400' 25sxs or 100' whichever greater. TAG
- 4) Set plug at 1100' 25sxs or 100' whichever is greater. TAG
- 5) Set plug at 251' 25sxs or 100' whichever is greater. TAG
- 6) Set surface plug 10sxs or 60' whichever is greater.

Place mud laden fluid between each plug w/12.5 lb/gal salt gel.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOC guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

Type or print name

E-mail address:

Telephone No.

For State Use Only

APPROVED BY: Chris Williams TITLE \_\_\_\_\_

DATE 4/10/2008

Conditions of Approval (if any):