## State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

FILE IN TRIPLICATE NSERVATION DIVISION WELL API NO. 1220 South St. Francis Dr. DISTRICT I 1625 N. French Dr , Hobbs, NM 88240 30-025-29054 Santa Fe, NM 87505 JUN 1 1 2008 5. Indicate Type of Lease 1301 W. Grand Ave, Artesia, NM 88210 STATE 6 State Oil & Gas Lease No. DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 7. Lease Name or Unit Agreement Name (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A South Hobbs (G/SA) Unit DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals.) Section 5 8 Well No. 194 1. Type of Well. Oil Well X Gas Well 9. OGRID No. 157984 2. Name of Operator Occidental Permian Ltd. 10 Pool name or Wildcat Hobbs (G/SA) / 3. Address of Operator HCR 1 Box 90 Denver City, TX 79323 4. Well Location Feet From The Line Feet From The 2310 East Unit Letter O South 330 NMPM County Section 19-S 38-E 11. Elevation (Show whether DF, RKB, RT GR, etc.) 3613' GL Pit or Below-grade Tank Application or Closure Distance from nearest fresh water well \_\_\_\_\_\_ Distance from nearest surface water Pit Type Depth of Ground Water Below-Grade Tank: Volume \_\_\_\_\_\_ bbls; Construction Material Pit Liner Thickness \_\_\_\_ Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 12. SUBSEQUENT REPORT OF: NOTICE OF INTENTION TO: ALTERING CASING PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPNS. PLUG & ABANDONMENT CHANGE PLANS TEMPORARILY ABANDON CASING TEST AND CEMENT JOB PULL OR ALTER CASING Multiple Completion OTHER. OTHER. Х Clean out/Squeeze/OAP/Acid treat 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. 1. Kill well. POOH w/ESP equipment. 2. Clean out to PBTD @4181'. 3. Plug back w/CIBP set @4100' capped w/10 of sand. 4. Squeeze Grayburg perfs from 3990-4051'. 5. Drill out squeeze and test. 6. Drill out to new PBTD @4275'. 7. Perforate well. 8. Acid treat. 9. Perform scale squeeze. 10. Run back in hole w/ESP equipment and return well to production. I hereby certify that the information above is true and complete to the best of my knowledge and belief I further certify that any pit or below-grade tank has been/will be closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan mov**SIGNATURE** TITLE Administrative Associate DATE 06/10/2008 TYPE OR PRINT NAME TELEPHONE NO E-mail address: mendy\_johnson@oxy.com 806-592-6280 For State Use Only PETROLEUM ENGINEER APPROVED BY

CONDITIONS OF APPROVAL IF ANY: