
SEP-1-7-2008	UNITEDSTATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT  NOTICES AND REPORTS ON WELLS his form for proposals to drill or to re-enter an ell. Use Form 3160-3 (APD) for such proposals.	FORMAPPROVED M B No 1004-0137 HOBB Sepires: March 31, 2007  5. Lease Serial No. LC-057210  6. If Indian, Allottee or Tribe Name
SUBMIT IN TR	PLICATE - Other instructions on reverse side.	7. If Unit or CA/Agreement, Name and/or No.
Type of Well     OilWell     Name of Operator     Conoco Phillips Company	Gas Well X Other	8. Well Name and No.  MCA  9. API Well No.
3a. Address 3300 N. "A" Street, Bldg. 4. Location of Well (Footage, Se	3b. PhoneNo.(include area code) 6, Midland TX 79705 (432)688-6884 c., T., R., M., or Survey Description)	30-025- See AHache 10. Field and Pool, or Exploratory Area Maljamar; Grayburg-San Andres
T-17-S, R-32-E & R-33-E		11. County or Parish, State Lea New Mexico
12. CHECK AI	PPROPRIATE BOX(ES)TO INDICATE NATURE OF NOTICE, R	EPORT, OR OTHER DATA
TYPE OF SUBMISSION	TYPE OF ACTION	
<ul><li></li></ul>	Acidize Deepen Production (State AlterCasing FractureTreat Recomplete  Casing Repair New Construction Recomplete  X Change Plans Plug and Abandon Temporarily Ab  Convert to Injection Plug Back Water Disposal	Well Integrity Other
If the proposal is to deepen dire Attach the Bond under which t following completion of the inv	ed Operation (clearly state all pertinent details, including estimated starting date of actionally or recomplete horizontally, give subsurface locations and measured and to he work will be performed or provide the Bond No. on file with BLM/BIA. Requivalved operations. If the operation results in a multiple completion or recompletion al Abandonment Notices shall be filed only after all requirements, including reclam of for final inspection.)	rue vertical depths of all pertunent markers and zones red subsequent reports shall be filed within 30 days in a new interval, a Form 3160-4 shall be filed once
Ref. Bond #ES0085		
Referencing Master Drill submit the attached mod	ing Plan on file with the BLM Carlsbad office dated 02/28 lifications to the cement program sections of the Master	3/2008. ConocoPhillips wishes to Drilling Plan:
Pg. 7 WOC time chan	Lead Slurry Density Change from 13.1 to 13.5 ppg ge from 24 to 18 hrs.	APPROVED

Pg. 7	8-5/8" Surf. Csg. Lead Slurry Density Change from 13.1 to 13.5 ppg	•
Pg. 7	WOC time change from 24 to 18 hrs.	
Pg. 8	5-1/2" Prod. Csg. Tail Slurry Density Change from 16.4 to 14.8 ppg	
Pg. 9	5-1/2" Prod. Csg. Tail Slurry Density Change from 16.4 to 14.8 ppg	
Pg. 11	5-1/2" Prod. Csg. Tail Slurry Density Change from 16.4 to 14.8 ppg	

Updated pages are attached for your convience to insert into the master document.

Your consideration given this request is greatly appreciate	ed.			LES PETROLE	S BABY/ EUM EN	
14. I hereby certify that the foregoing is true and correct Name (Printed/Typed)	<u> </u>		·~~~	en jaer magen.	C 17701 -24	a not mandomen - notice
Celeste G. Dale	Title	Regulatory Specia	alist 🗸	br. Mengarithment	(PT MAD ORTHOGRAM	
Signature Collecte Acalal	Date	06/16/2008			ş	
THIS SPACE FOR FEDERAL	OR	STATE OFFICE U	SE		1	
Approved by		Title		Date		
Conditions of approval, if any, are attached. Approval of this notice does not warm certify that the applicant holds legal or equitable title to those rights in the subject which would entitle the applicant to conduct operations thereon.	1	Office /	云			
Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for ar States any false, fictitious or fraudulent statements or representations as tolany	y person	n knowingly and willfully to r within its jurisdiction.	nake to	any departme	nt or agenc	cy of the United

(Instructions on page 2)



## 4. Proposed cementing program:

For the cementing program a range is presented for the number of sacks of cement and for the bottom, top, and length of the lead slurries and tail slurries due to the variation in formation tops and planned TD for the planned / contemplated wells for which this Master Drilling Plan is intended.

# 13-3/8" Conductor:

Cement to surface with ready mix or Class C Neat cement. TOC at surface.

### 8-5/8" Surface Casing:

The intention for the cementing program for the Surface Casing is to:

- Place the Tail Slurry from the casing shoe to 300' above the casing shoe,
- Bring the Lead Slurry to surface.

Spacer: 20 bbls Fresh Water

Lead Slurry				·				
Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx		ve Strengths y UCA Method
185 – 535 sx Class C + 6% bentonite + 2% CaCl2 + 0.125% Polyflake	325 to 940	Surface	325 to 940	13.5	1.96	10.69	Time 12 hrs 18 hrs 24 hrs	Strength 316 psi 417 psi 506 psi
Excess = 170%								

Tail Slurry								
Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx		ve Strengths by UCA Method
220 sx Class C + 2% CaCl2 + 0.125% Polyflake Excess = 100%	625' to 1240'	325' to 940'	300'	14.8	1.35	6.36	Time 3 hrs 9 hrs 12 hrs 24 hrs 48 hrs	Strength 50 psi 500 psi 793 psi 1266 psi 2183 psi

Displacement: Fresh Water

Note: In accordance with the Pecos District Conditions of Approval, we will Wait on Cement (WOC) for a period of not less than 18 hrs after placement of the cement on the Surface Casing in order to achieve at least 500 psi compressive strength in both the Lead Slurry and Tail Slurry cements prior to drilling out of the Surface Casing.

# 5-1/2" Production Casing Cementing Program - Single Stage Cementing Option:

The intention for the cementing program for the Production Casing – Single Stage Cementing Option is to:

- Place the Tail Slurry from the casing shoe to the top of the Grayburg formation,
- Bring the Lead Slurry to surface.

Spacer: 20 bbls Fresh Water with an option to follow this with 1000 gallons SuperFlush 102 and 20 additional bbls Fresh Water.

Volume (sx)	Bottom	Тор	Length	Density	Yield	Mix Wtr	Comp	ressive
& Recipe & Excess %	(ft MD)	(ft MD)	(ft)	(ppg)	(cuft/sx)	gal/sx		ngths
·								deg F by Method
433 – 644 sx 50% Class C 50% POZ + 10% bentonite + 8 lb/sx Salt + 0.2% Fluid Loss Additive + 0.125% Polyflake	3270' to 3940'	Surface	3270' to 3940'	11.8	2.55	14.88	Time 12 hrs 24 hrs 48 hrs 72 hrs	Strength 100 psi 200 psi 245 psi 310 psi

Volume (sx)	Bottom	Top	Length	Density	Yield	Mix Wtr	Compressive Strengths  @ 115 deg F by UCA Metho	
& Recipe & Excess %	(ft MD)	(ft MD)	(ft)	(ppg)	(cuft/sx)	gal/sx		
150 – 285 sx 65% Class C 35% POZ + 0.4% Dispersant	4155' to 4705'	3270' to 3940'	636' to 885'	14.8	0.98	3.76	Time 5 hrs 56 min 8 hrs 12 min 24 hrs 48 hrs 72 hrs	Strength 50 psi 500 psi 2806 psi 4690 psi 5661 psi

Displacement: 2% KCL water with approximately 250 ppm gluteraldehyde biocide.

# 5-1/2" Production Casing Cementing Program - Two-Stage Cementing Option (for Loss of Circulation Events):

We propose an option to use the two-stage cementing method for cementing the production casing if any loss of circulation events or heavy seepage is experienced while drilling the 7-7/8" hole. (see discussion in Item 3 above). The proposed two-stage cementing program would be as follows:

- Stage 1: Would place cement from the casing shoe to the stage tool.
- Stage 2: Would place cement from the stage tool to Surface.

## Stage 1:

Spacer: 20 bbls Fresh Water with an option to follow this with 1000 gallons SuperFlush 102 and 20 additional bbls Fresh Water

# Stage 1 - Lead Surry: None

followed by brine based mud.

Stage 1 – Tail Slurry Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx	Compressive @ 113 deg F by	
150 – 285 sx 65% Class C 35% POZ + 0.4% Dispersant	4155' to 4705'	3270' to 3940'	636' to 885'	14.8	0.98	3.76	Time 5 hrs 56 min 8 hrs 12 min 24 hrs 48 hrs 72 hrs	Strength 50 psi 500 psi 2806 psi 4690 psi 5661 psi

Displacement: A volume of Fresh Water equal to the capacity volume from the stage tool to the float collar,

# 5-1/2" Production Casing Cementing Program – Two-Stage Cementing Option with Stage Tool and External Casing Packers (for Water Flow Events):

We propose an option to use the two-stage cementing method with a Stage Tool and two each External Casing Packers if any waterflow event is experienced while drilling the 7-7/8" hole as discussed above in Item 3. The proposed two-stage cementing program would be as follows:

- Stage 1: Would place cement from the casing shoe to the stage tool
- Stage 2: Would place cement from the stage tool to Surface.

## Stage 1:

Spacer: 20 bbls Fresh Water with an option to follow this with 1000 gallons SuperFlush 102 and 20 additional bbls Fresh Water

Stage 1 - Lead Slurry Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx	Compressive @ 113 deg F by	
77 – 363 sx 50% Class C 50% POZ + 10% bentonite + 8 lb/sx Salt + 0.2% Fluid Loss Additive + 0.125% Polyflake	3270' to 3940'	1670' to 3440'	500' to 1600'	11.8	2.55	14.88	Time 12 hrs 24 hrs 48 hrs 72 hrs	Strength 100 psi 200 psi 245 psi 310 psi

Stage 1 - Tail Slurry Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx	Compressive @ 113 deg F by	
150 – 285 sx 65% Class C 35% POZ + 0.4% Dispersant	4155' to 4705'	3270' to 3940'	636' to 885'	14.8	0.98	3.76	Time 5 hrs 56 min 8 hrs 12 min 24 hrs 48 hrs 72 hrs	Strength 50 psi 500 psi 2806 psi 4690 psi 5661 psi

Displacement: A volume of Fresh Water equal to the capacity volume from the stage tool to the float collar, followed by brine based mud.