	UNITEDSTAT DEPARTMENT OF TH BUREAU OF LAND MA		OCD _{CD}	FORMAPPROVED OM B No 1004-0137 Expires: March 31, 2007 5. Lease Serial No.
SEP Do not USP to	NOTICES AND R his form for proposals rell. Use Form 3160-3	s to drill or to re-e	enter an	6. If Indian, Allottee or Tribe Name
1. Type of Well X Oil Well	Gas Well X Other	·	rse side.	7. If Unit or CA/Agreement, Name and/or No
2. Name of Operator Conoco Phillips Company				8. Well Name and No. MCA 9. API Well No.
3a. Address 3300 N. "A" Street, Bldg.	6, Midland TX 79705			30-025- Sec AHachec 10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Se T-17-S, R-32-E & R-33-E	•	cription)		Maljamar; Grayburg-San Andres 11. County or Parish, State Lea New Mexico
12. CHECK AI	PPROPRIATE BOX(ES)T	O INDICATE NATU	RE OF NOTICE, RI	EPORT, OR OTHER DATA
TYPEOF SUBMISSION		TY	PEOF ACTION	ı
X Notice of Intent Subsequent Report	Acidize AlterCasing Casing Repair	Deepen FractureTreat New Construction	Production (Sta Reclamation Recomplete	Well Integrity Other
Final Abandonment Notice	Convert to Injection	Plugand Abandon Plug Back	Temporarily Aba	andon
If the proposal is to deepen dire	ectionally or recomplete horizon	tally, give subsurface location	ons and measured and tr	any proposed work and approximate duration thereof. ue vertical depths of all pertinent markers and zones red subsequent reports shall be filed within 30 days

following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Ref. Bond #ES0085

Referencing Master Drilling Plan on file with the BLM Carlsbad office dated 02/28/2008. ConocoPhillips wishes to submit the attached modifications to the cement program sections of the Master Drilling Plan:

Pg. 7	8-5/8" Surf. Csg. Lead Slurry Density Change from 13.1 to 13.5 ppg	,
Pg. 7	WOC time change from 24 to 18 hrs.	
Pg. 8	5-1/2" Prod. Csg. Tail Slurry Density Change from 16.4 to 14.8 ppg	
Pa. 9	5-1/2" Prod. Csg. Tail Slurry Density Change from 16.4 to 14.8 ppg	,

Pg. 9 5-1/2" Prod. Csg. Tail Sturry Density Change from 16.4 to 14.6 ppg Pg. 11 5-1/2" Prod. Csg. Tail Sturry Density Change from 16.4 to 14.8 ppg


Updated pages are attached for your convience to insert into the master document Your consideration given this request is greatly appreciated.

SEP 2 2008 LES BABYAK PETROLEUM ENGINEER

 I hereby certify that the foregoing is true and correct Name (Printed/Typed) 	ı	, ~ az • y	en - tre - in to the mounter a see in the handle deal in west
Celeste G. Dale	Title	Regulatory Specialist	, partition of the second process of the sec
Signature Cielecti Andali	Date	06/16/2008	
THIS SPACE FOR FEDERAL	ORS	STATE OFFICE USE	1
Approved by		Title	Date
Conditions of approval, if any, are attached. Approval of this notice does not warr certify that the applicant holds legal or equitable title to those rights in the subject which would entitle the applicant to conduct operations thereon.	1	Office Z	
Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for a	ny person	knowingly and willfully to make to	any department or agency of the United

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)



4. Proposed cementing program:

For the cementing program a range is presented for the number of sacks of cement and for the bottom, top, and length of the lead slurries and tail slurries due to the variation in formation tops and planned TD for the planned / contemplated wells for which this Master Drilling Plan is intended.

13-3/8" Conductor:

Cement to surface with ready mix or Class C Neat cement. TOC at surface.

8-5/8" Surface Casing:

The intention for the cementing program for the Surface Casing is to:

- Place the Tail Slurry from the casing shoe to 300' above the casing shoe,
- Bring the Lead Slurry to surface.

Spacer: 20 bbls Fresh Water

Lead Slurry Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx		ve Strengths y UCA Method
185 – 535 sx Class C + 6% bentonite + 2% CaCl2 + 0.125% Polyflake	325 to 940	Surface	325 to 940	13.5	1.96	10.69	Time 12 hrs 18 hrs 24 hrs	Strength 316 psi 417 psi 506 psi
Excess = 170%							1	

Tail Slurry							•	
Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx	Compressive Strengths @ 91 deg F by UCA Meth	
220 sx Class C + 2% CaCl2 + 0.125% Polyflake Excess = 100%	625' to 1240'	325' to 940'	300'	14.8	1.35	6.36	Time 3 hrs 9 hrs 12 hrs 24 hrs 48 hrs	Strength 50 psi 500 psi 793 psi 1266 psi 2183 psi

Displacement: Fresh Water

Note: In accordance with the Pecos District Conditions of Approval, we will Wait on Cement (WOC) for a period of not less than 18 hrs after placement of the cement on the Surface Casing in order to achieve at least 500 psi compressive strength in both the Lead Slurry and Tail Slurry cements prior to drilling out of the Surface Casing.

5-1/2" Production Casing Cementing Program - Single Stage Cementing Option:

The intention for the cementing program for the Production Casing – Single Stage Cementing Option is to:

- Place the Tail Slurry from the casing shoe to the top of the Grayburg formation,
- Bring the Lead Slurry to surface.

Spacer: 20 bbls Fresh Water with an option to follow this with 1000 gallons SuperFlush 102 and 20 additional bbls Fresh Water.

Lead Slurry		, <u>=</u>		T		T	· · ·	
Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx	Stre @ 113	oressive engths deg F by Method
433 – 644 sx 50% Class C 50% POZ + 10% bentonite + 8 lb/sx Salt + 0.2% Fluid Loss Additive + 0.125% Polyflake	3270' to 3940'	Surface	3270' to 3940'	11.8	2.55	14.88	Time 12 hrs 24 hrs 48 hrs 72 hrs	Strength 100 psi 200 psi 245 psi 310 psi

Volume (sx)	Bottom	Top	Length	Density	Yield	Mix Wtr	Compressive Strengths @ 115 deg F by UCA Metho	
& Recipe & Excess %	(ft MD)	(ft MD)	(ft)	(ppg)	(cuft/sx)	gal/sx		
150 – 285 sx 65% Class C 35% POZ + 0.4% Dispersant	4155' to 4705'	3270' to 3940'	636' to 885'	14.8	0.98	3.76	Time 5 hrs 56 min 8 hrs 12 min 24 hrs 48 hrs 72 hrs	Strength 50 psi 500 psi 2806 psi 4690 psi 5661 psi

Displacement: 2% KCL water with approximately 250 ppm gluteraldehyde biocide.

5-1/2" Production Casing Cementing Program - Two-Stage Cementing Option (for Loss of Circulation Events):

We propose an option to use the two-stage cementing method for cementing the production casing if any loss of circulation events or heavy seepage is experienced while drilling the 7-7/8" hole. (see discussion in Item 3 above). The proposed two-stage cementing program would be as follows:

- Stage 1: Would place cement from the casing shoe to the stage tool.
- Stage 2: Would place cement from the stage tool to Surface.

Stage 1:

Spacer: 20 bbls Fresh Water with an option to follow this with 1000 gallons SuperFlush 102 and 20 additional bbls Fresh Water

Stage 1 – Lead Surry: None

Volume (sx)	Bottom	Top	Length	Density	Yield	Mix Wtr	Compressive	
& Recipe & Excess %	(ft MD)	(ft MD)	(ft)	(ppg)	(cuft/sx)	gal/sx	@ 113 deg F by	
150 – 285 sx 65% Class C 35% POZ + 0.4% Dispersant	4155' to 4705'	3270' to 3940'	636' to 885'	14.8	0.98	3.76	Time 5 hrs 56 min 8 hrs 12 min 24 hrs 48 hrs 72 hrs	Strength 50 psi 500 psi 2806 psi 4690 psi 5661 psi

Displacement: A volume of Fresh Water equal to the capacity volume from the stage tool to the float collar, followed by brine based mud.

5-1/2" Production Casing Cementing Program – Two-Stage Cementing Option with Stage Tool and External Casing Packers (for Water Flow Events):

We propose an option to use the two-stage cementing method with a Stage Tool and two each External Casing Packers if any waterflow event is experienced while drilling the 7-7/8" hole as discussed above in Item 3. The proposed two-stage cementing program would be as follows:

- Stage 1: Would place cement from the casing shoe to the stage tool
- Stage 2: Would place cement from the stage tool to Surface.

Stage 1:

Spacer: 20 bbls Fresh Water with an option to follow this with 1000 gallons SuperFlush 102 and 20 additional bbls Fresh Water

Stage 1 – Lead Slurry								
Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx	Compressive S @ 113 deg F by Cı	
77 – 363 sx 50% Class C 50% POZ + 10% bentonite + 8 lb/sx Salt + 0.2% Fluid Loss Additive + 0.125% Polyflake	3270' to 3940'	1670' to 3440'	500' to 1600'	11.8	2.55	14.88	Time 12 hrs 24 hrs 48 hrs 72 hrs	Strength 100 psi 200 psi 245 psi 310 psi

Stage 1 – Tail Slurry Volume (sx) & Recipe & Excess %	Bottom (ft MD)	Top (ft MD)	Length (ft)	Density (ppg)	Yield (cuft/sx)	Mix Wtr gal/sx	Compressive @ 113 deg F by	
150 – 285 sx 65% Class C 35% POZ + 0.4% Dispersant	4155' to 4705'	3270' to 3940'	636' to 885'	14.8	0.98	3.76	Time 5 hrs 56 min 8 hrs 12 min 24 hrs 48 hrs 72 hrs	Strength 50 psi 500 psi 2806 psi 4690 psi 5661 psi

Displacement: A volume of Fresh Water equal to the capacity volume from the stage tool to the float collar, followed by brine based mud.