Submit 5 copies to Appropri	ate District State of New Mexic	co	Form C-103
Office District I	State of New Mexic State of New Mexic Minerals and Natural M 88240	Resources	June 19, 2008
1625 N French Dr., Hobbs, N	IM 88240	WELL	API NO.
District II	FEB 02 2000 CONCEDIVATION D	IVISION	30-025-06137
1301 W Grand Ave , Artesia	NM 88210 A CARDON D	5. Indi	icate Type of Lease
District IV District IV District IV Artesia, NM 88210 ARECONSERVATION DIVISION AREA DISTRICT DIVISION AREA DISTRICT DIVISION Santa Fe, NM 87505		S Dr.	STATE FEE
District IV	Santa Fe, NM 8750	6. Stat	e Oil & Gas Lease No.
1220 S St Francis Dr, Santa	Fe, NM		
87505	DRY MOTIOES AND DEPORTS ON WELLS	7 1 00	as Name on Unit Assessment Name
	DRY NOTICES AND REPORTS ON WELLS FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG		se Name or Unit Agreement Name
	USE "APPLICATION FOR PERMIT" (FORM C-101) FOR S	T LOT T	State II 17
PROPOSALS.)			State H-17
1. Type of Well: Oil V	/ell ☐ Gas Well ☒ Other	8. We	ll Number 2
2. Name of Operator		9. OG	RID Number 143199
EnerVest Operati	ng, L.L.C.		
3. Address of Operator		10. Po	ool name or Wildcat
1001 Fannin, Sui	te 800 Houston, TX 77002	E	umont (Yates-7R-Qn) (Gas)
4. Well Location			
Unit Letter	D: 330 feet from the North line an	d 330 feet from the	West line
<u> </u>			
Section	Township 20S Range		County Lea
	11. Elevation (Show whether DR, RI	(B, RT, GR, etc.)	
And the second second	GR = 3,542		
12	. Check Appropriate Box to Indicate Natu	are of Notice, Report	or Other Data
NOTIC	CE OF INTENTION TO:	SUBSEQU	ENT REPORT OF:
PERFORM REMEDIAL	WORK ☐ PLUG AND ABANDON ☐ R	EMEDIAL WORK	☐ ALTERING CASING ☐
TEMPORARILY ABANI	DON 🗌 CHANGE PLANS 🔲 🗀	OMMENCE DRILLING C	PNS P AND A
PULL OR ALTER CASI	NG 🗌 MULTIPLE COMPL 🔲 🗀	ASING/CEMENT JOB	
DOWNHOLE COMMIN	GLE		
DOMAIN IOLL COMMINING	JLL		
DOWN IOLL COMMIN	SLL []		
OTHER: WORKOVER	R to acidize existing perfs 3041'-3348'.	THER:	
OTHER: WORKOVER	_		ertinent dates, including estimated date
OTHER: WORKOVER	R to acidize existing perfs 3041'-3348'.	inent details, and give pe	
OTHER: WORKOVER	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple (inent details, and give pe	
OTHER: WORKOVER 13. Describe propose of starting any proposed in the starting and proposed in the star	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple (inent details, and give pe	
OTHER: WORKOVER 13. Describe propose of starting any proposed in the starting and proposed in the star	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple 0. RU air foam unit & clean out to PBTD @ 3,408	inent details, and give pe Completions: Attach wel '. RIH w/ tbg & pkr & s	lbore diagram of proposed completion et pkr @ 2,980'. Load & test
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Deed or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple 0	inent details, and give pe Completions: Attach wel '. RIH w/ tbg & pkr & s	lbore diagram of proposed completion et pkr @ 2,980'. Load & test
OTHER: WORKOVER 13. Describe propos of starting any p or recompletion	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple 0. RU air foam unit & clean out to PBTD @ 3,408	inent details, and give pe Completions: Attach wel '. RIH w/ tbg & pkr & s ws: 5,000 gals 15% NEI	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers.
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple 0. RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as follows.	inent details, and give per Completions: Attach wel '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 n	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight,
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple 0 and the second work of the	inent details, and give per completions: Attach welest. Attach wells. Attach we	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all per proposed work). SEE RULE 1103. For Multiple 0 and 20 are state all per proposed work). RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as folloop Note breakdown press, rate, ball action & press, depending on time). Open well, check & note press.	inent details, and give per Completions: Attach weles. Attach weles. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J & RIH w/ 3-1/2" BPMA	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all per proposed work). SEE RULE 1103. For Multiple of the complete state all per proposed work). SEE RULE 1103. For Multiple of the complete state all per proposed work). SEE RULE 1103. For Multiple of the complete state all per proposed work and the complete state all per	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEI Note ISDP & 5/10/15 nress; blow to tank & RU J & RIH w/ 3-1/2" BPM/ RIH w/ gas anchor, pun	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple of the complete operations are stated as a service and the complete operations. RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as follood breakdown press, rate, ball action & press depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Publow btm perf as possible. NDBOP, NUWH	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEI Note ISDP & 5/10/15 nress; blow to tank & RU J & RIH w/ 3-1/2" BPM/ RIH w/ gas anchor, pun	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple of the complete operations are stated as a service and the complete operations. RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as follood breakdown press, rate, ball action & press depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Publow btm perf as possible. NDBOP, NUWH	inent details, and give per Completions: Attach weld a completions: Attach weld a completions: Attach weld a completions: 5,000 gals 15% NEI Note ISDP & 5/10/15 moress; blow to tank & RU J& RIH w/ 3-1/2" BPM/RIH w/ gas anchor, purpose complete in the com	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple of the complete operations are stated as a service and the complete operations. RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as follood breakdown press, rate, ball action & press depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Publow btm perf as possible. NDBOP, NUWH	inent details, and give per Completions: Attach weld a completions: Attach weld a completions: Attach weld a completions: 5,000 gals 15% NEI Note ISDP & 5/10/15 moress; blow to tank & RU J& RIH w/ 3-1/2" BPM/RIH w/ gas anchor, purpose complete in the com	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple of the complete operations are stated as a service and the complete operations. RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as follood breakdown press, rate, ball action & press depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Publow btm perf as possible. NDBOP, NUWH	inent details, and give per Completions: Attach weld a completions: Attach weld a completions: Attach weld a completions: 5,000 gals 15% NEI Note ISDP & 5/10/15 moress; blow to tank & RU J& RIH w/ 3-1/2" BPM/RIH w/ gas anchor, purpose complete in the com	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far
OTHER: WORKOVER 13. Describe propose of starting any proor recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple Composed work). SEE RULE 1103. For Multiple Composed work is seen out to PBTD @ 3,408 backside. MIRU acid service & acidize as followed breakdown press, rate, ball action & press. depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Pload below btm perf as possible. NDBOP, NUWH & test. Ensure good pump action. Place on process.	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J& RIH w/ 3-1/2" BPMARIH w/ gas anchor, punduction.	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propose of starting any proposed or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple of the complete operations are stated as a service and the complete operations. RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as follood breakdown press, rate, ball action & press depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Publow btm perf as possible. NDBOP, NUWH	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J& RIH w/ 3-1/2" BPMARIH w/ gas anchor, punduction.	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propose of starting any proor recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple Composed work). SEE RULE 1103. For Multiple Composed work is seen out to PBTD @ 3,408 backside. MIRU acid service & acidize as followed breakdown press, rate, ball action & press. depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Pload below btm perf as possible. NDBOP, NUWH & test. Ensure good pump action. Place on process.	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J& RIH w/ 3-1/2" BPMARIH w/ gas anchor, punduction.	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propose of starting any proor recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple Composed work). SEE RULE 1103. For Multiple Composed work is seen out to PBTD @ 3,408 backside. MIRU acid service & acidize as followed breakdown press, rate, ball action & press. depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Pload below btm perf as possible. NDBOP, NUWH & test. Ensure good pump action. Place on process.	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J& RIH w/ 3-1/2" BPMARIH w/ gas anchor, punduction.	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propos of starting any p or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple of the respective state all perproposed work). SEE RULE 1103. For Multiple of the respective state all perproposed work). RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as follow states below breakdown press, rate, ball action & press. depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Pto below btm perf as possible. NDBOP, NUWH & test. Ensure good pump action. Place on prospective states are good pump action.	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J & RIH w/ 3-1/2" BPM/ RIH w/ gas anchor, punduction.	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propos of starting any p or recompletion Workover details:	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple Composed work). SEE RULE 1103. For Multiple Composed work is seen out to PBTD @ 3,408 backside. MIRU acid service & acidize as followed breakdown press, rate, ball action & press. depending on time). Open well, check & note pload; note fluid level, swab rate & gas blow. Pload below btm perf as possible. NDBOP, NUWH & test. Ensure good pump action. Place on process.	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J & RIH w/ 3-1/2" BPM/ RIH w/ gas anchor, punduction.	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propose of starting any propose of starting and proposed of starti	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perforoposed work). SEE RULE 1103. For Multiple of the performance of the p	inent details, and give per Completions: Attach well and its completions: Attach well are seen as a seen a	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propose of starting any propose of starting and proposed of starti	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perforoposed work). SEE RULE 1103. For Multiple of the performance of the p	inent details, and give per Completions: Attach well and its completions: Attach well are seen as a seen a	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propose of starting any propose of starting and proposed of starti	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perforoposed work). SEE RULE 1103. For Multiple of RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as folloon Note breakdown press, rate, ball action & press. depending on time). Open well, check & note produced in the performance of the performance	inent details, and give per Completions: Attach well '. RIH w/ tbg & pkr & sws: 5,000 gals 15% NEF Note ISDP & 5/10/15 nress; blow to tank & RU J & RIH w/ 3-1/2" BPM/ RIH w/ gas anchor, punduction.	et pkr @ 2,980°. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load
OTHER: WORKOVER 13. Describe propose of starting any progression of starting and proposed of starting and proposed of starting and progression of starting and proposed of	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perforoposed work). SEE RULE 1103. For Multiple of the proposed work). SEE RULE 1103. For Multiple of the performance of the perform	inent details, and give per Completions: Attach well and it is a completion of my knowledge and before Tech.	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load Total Company Company Total Company Company Total Company Company Company Total Company Company Company Company Total Company Company Company Company Company Total Company
OTHER: WORKOVER 13. Describe propose of starting any progression. Workover details: Spud Date: I hereby certify that the interpretation. Type or print name	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perforoposed work). SEE RULE 1103. For Multiple of RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as folloon Note breakdown press, rate, ball action & press. depending on time). Open well, check & note produced in the performance of the performance	inent details, and give per Completions: Attach well and it is a completion with the completion with the completion with the complete with	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load Total Company Company Total Company Company Total Company Company Company Total Company Company Company Company Total Company Company Company Company Company Total Company
OTHER: WORKOVER 13. Describe propose of starting any progression of starting and proposed of starting and proposed of starting and progression of starting and proposed of	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perforoposed work). SEE RULE 1103. For Multiple of RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as folloon Note breakdown press, rate, ball action & press. depending on time). Open well, check & note produced in the performance of the performance	inent details, and give per Completions: Attach well and it is a completion with the completion with the completion with the complete with	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load Total Company of the proposed completion Total Company of the proposed co
OTHER: WORKOVER 13. Describe propose of starting any progression. Workover details: Spud Date: I hereby certify that the interpretation. Type or print name	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perforoposed work). SEE RULE 1103. For Multiple of RU air foam unit & clean out to PBTD @ 3,408 backside. MIRU acid service & acidize as folloon Note breakdown press, rate, ball action & press. depending on time). Open well, check & note produced in the performance of the performance	inent details, and give per Completions: Attach well and it is a completion of my knowledge and before Tech.	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. nin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load Total Company Company Total Company Company Total Company Company Company Total Company Company Company Company Total Company Company Company Company Company Total Company
OTHER: WORKOVER 13. Describe propose of starting any progression. Workover details: Spud Date: I hereby certify that the interpretation. Type or print name	R to acidize existing perfs 3041'-3348'. Red or completed operations. (Clearly state all perproposed work). SEE RULE 1103. For Multiple of the proposed work of t	inent details, and give per Completions: Attach well and it is a completion with the completion with the completion with the complete with	et pkr @ 2,980'. Load & test FE w/ clay stabilizer & 68 ball sealers. hin SDP. SI for 4hrs (or overnight, swab equip. Attempt to swab back AJ, perf sub, SN & tbg. Set SN as far np & rods. Space out, hang on, load The stable of the stable o