

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St Francis Dr., Santa Fe, NM  
87505

State of New Mexico

Conservation Minerals and Natural Resources

Form C-103

June 19, 2008

RECEIVED

MAY 20 2009 CONSERVATION DIVISION

HOBBS

1220 South St. Francis Dr.  
Santa Fe, NM 87505

PAGE 1 OF 1

WELL API NO. 3000500658
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-8664
7. Lease Name or Unit Agreement Name SOUTH CAPROCK QUEEN UNIT
8. Well Number 010
9. OGRID Number 12627
10. Pool name or Wildcat 08559 CAPROCK QUEEN
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 4441' GR

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS.)

1. Type of Well: Oil Well Gas Well ☒ Other INJECTION

2. Name of Operator  
KEVIN O BUTLER & ASSOCIATES, INC.

3. Address of Operator  
PO BOX 1171, MIDLAND, TEXAS 79702

4. Well Location

Unit Letter J 1980 feet from the SOUTH line and 1980 feet from the EAST line  
Section 30 Township 15S Range 31E NMPM CHAVES County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
4441' GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
DOWNHOLE COMMINGLE ☐

OTHER: WORKOVER

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER:

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Move in rig up well service unit. POOH with tubing and packer. Pick up work string and tally in hole to tag bottom. Pump sand to cover perforations and 50' above. POOH with work string and stand in derrick. Pick up 4 1/2" float shoe, one joint 4 1/2" casing, one float collar, and 4 1/2" casing with 4.875" OD collars. RIH with 4 1/2" casing to within 75' of the top of the perforations. Change over well head to accept 4 1/2" casing. Install 4 1/2" bell nipple. Rig up cement truck and cement liner to the surface. Wait on cement to cure at least 24 hours. Pick up bit, drill collars and RIH with work string. Drill out float collar, cement and float shoe. Clean out to bottom removing sand. RIH with packer and test to 500#. Lay down work string. Return well to injection with packer and tubing.


Approximate start date 6/3/2009.

Run MIT BEFORE  
RETURNING TO INJ.

Spud Date:


Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE  TITLE President/Owner DATE 5/19/09

Type or print name KEVIN O BUTLER E-mail address: robie@geedmidland.com PHONE: 432-682-1178

For State Use Only

APPROVED BY:  TITLE PETROLEUM ENGINEER DATE MAY 28 2009

Conditions of Approval (if any):