Office DE SERVE AND	Form C-103
Office District I 1625 N. French Dr. Hobbs NM 88240	June 19, 2008
1025 N Fichell DI , 110008, NW 06240	WELL API NO. 30-05-28017
1301 W. Grand Ave , Artesia, NM 88970 Z / 79111 CONSERVATION DIVISION	5 Indicate Type of Lease
District III 1220 South St. Francis Dr.	STATE FEE STATE
1220 S St. Francis Dr , Santa Fe, NM	6 State Oil & Gas Lease No.
87505 SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	Cato San Andres Unit
1 Type of Well: Oil Well Gas Well Other	8. Well Number 574
2 Name of Operator Cano Petro of New Mexico, INC.	9. OGRID Number 248802
3. Address of Operator 801 Cherry St. Unit 25 Suite 3200 Ft. Worth, TX 76102	10. Pool name or Wildcat CATO; SAN ANDRES
4. Well Location	
Unit Letter H . 1365 feet from the North line and 12	
Section 14 Township 08S Range 30E	NMPM 27 County Chaves
11 Elevation (Show whether DR, RKB, RT, GR, etc. 4144 DF	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: SUB	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL WOR	K ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DR	
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMEN	T JOB 🗵
DOWNHOLE COMMINGLE	
OTHER. OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, an	d give pertinent dates, including estimated date
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions. A	d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an	d give pertinent dates, including estimated date ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions. A or recompletion.	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions. A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions. A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions. A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg.	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid.	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600'	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid.	ttach wellbore diagram of proposed completion
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit	ing. Cement
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600'	ing. Cement
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit	ing. Cement
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit Spud Date 4-15-2008 Rig Release Date. 4-23-	ing. Cement
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit	ing. Cement
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit Spud Date 4-15-2008 Rig Release Date. 4-23-	ing. Cement
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit Spud Date 4-15-2008 Rig Release Date. 4-23- TITLE Engineer	trach wellbore diagram of proposed completion ing. Cement 2008 e and belief. DATE 4-20-09
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit Spud Date 4-15-2008 Rig Release Date. 4-23- Title Engineer Type or print name Collin Strawn E-mail address:	trach wellbore diagram of proposed completion ing. Cement 2008 e and belief. DATE 4-20-09 PHONE. 817-698-0900
13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: A or recompletion. Work Over: 4-15-08 Rig Up Drill 12 1/4 hole to set 858' 8 5/8" 24# cas with 550 sx Class C Cement 4-16-08 Install BOP & Begin Drill w/7 7/8" bit 4-22-08 TD Well TOOH to log Run 4045' 5.5" 15.5# csg. 4-23-08 Cement with 1000 sx cement Completion: 4-30-08 Log & Perforate 3504-44, 3572-84 5-1-08 Acidize w/8000 gal 28% acid. 5-2-08 Run tubing & Rods set @ 3600' 5-3-08 Install Unit Spud Date 4-15-2008 Rig Release Date. 4-23- TITLE Engineer	2008 2008 DATE 4-20-09 PHONE. 817-698-0900