

Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Ave., Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87401

District IV

1220 S. St. Francis Dr., Santa Fe, NM

87505

Energy, Minerals and Natural Resources

June 19, 2008

RECEIVED

SEP 04 2009

OIL CONSERVATION DIVISION

1220 South St. Francis Dr.

Santa Fe, NM 87505

WELL API NO.

30-025-29648

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil &amp; Gas Lease No.

LG-6940

7. Lease Name or Unit Agreement Name

Reeves ADQ State

8. Well Number

1

9. OGRID Number

255333

10. Pool name or Wildcat

Reeves Delaware

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

Lime Rock Resources A, L.P.

3. Address of Operator

Heritage Plaza, 1111 Bagby St. Suite 4600, Houston, TX 77002

4. Well Location

Unit Letter: A: 700 feet from the North line and 700 feet from the East line

Section

14

Township

18S

Range

35E

NMPM Lea County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

3,884.6' GR

## 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

## NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
 TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
 PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
 DOWNHOLE COMMINGLE ☐

OTHER: ☐

## SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
 COMMENCE DRILLING OPNS. ☐ P AND A ☐  
 CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

## Plugging Procedure:

1. Pull rods and pump. Pull 2-7/8" production tubing.
2. Set CIBP @ 5,750' and place 35' of cement on top of plug.
3. TIH with tubing and load hole with mud. POOH with tubing.
4. Perforate casing @ 4,900' and place 100' cement plug from 4,800' to 4,900'. WOC and tag plug. 25 SXS CMT OR >
5. Perforate casing @ 3,860' and place 100' cement plug from 3,760' to 3,860'. WOC and tag plug. 25 SXS CMT OR >
6. Perforate casing @ 485' and place 100' cement plug from 385' to 485'. WOC and tag plug. 25 SXS CMT OR >
7. Perforate casing @ 60' and circulate casing full of cement back to surface.
8. Cut off wellhead and install dry hole marker.
9. Cut off anchors, fill in cellar, and restore location.

The Oil Conservation Division **Must be notified**  
**24 hours prior** to the beginning of plugging operations

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

C. Tim Miller

TITLE Vice President - Operations

DATE 02 September 2009

Type or print name C. Tim Miller

E-mail address: tmiller@limerockresources.com

PHONE: (713) 292-9514

For State Use Only

APPROVED BY:

Makayla Brown

TITLE

Compliance Officer

DATE


9/9/2009

Conditions of Approval (if any)



**LIME ROCK  
RESOURCES**

## PROPOSED ABANDONMENT



<u>Zone</u>	<u>Top</u>
Queen	4,414'
San Andres	4,820'
Delaware	5,629'
Bone Springs	6,668'
Strawn	10,920'

**Lime Rock Resources  
Reeves ADQ State 1  
Sec 14-18S-35E  
Lea County, NM**