

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

OCD-HOBBS

FORM APPROVED  
OMB No 1004-0137  
Expires July 31, 2010

**SUNDRY NOTICES AND REPORTS ON WELLS**  
***Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.***

5 Lease Serial No.  
LC031695B

6. If Indian, Allottee or Tribe Name

**SUBMIT IN TRIPLICATE – Other instructions on page 2.**

1. Type of Well

☐ Oil Well

☒ Gas Well

☒ Other

Ing

2. Name of Operator  
ConocoPhillips Company

3a. Address  
P.O. Box 51810  
Midland, Texas 79710-1810

3b. Phone No. (include area code)  
432-688-6913

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
1980 FNL & 1980 FEL, UL G, Section 33, T20S, R38E

7. If Unit of CA/Agreement, Name and/or No.

NM 71052 E

8. Well Name and No.  
Warren Unit B/T WF #80

9. API Well No.  
30-025-26642

10. Field and Pool or Exploratory Area  
Warren: Blinbry/Tubb O&G

11. Country or Parish, State  
Lea, NM

**12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA**

TYPE OF SUBMISSION	TYPE OF ACTION			
<input checked="" type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input checked="" type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other
	<input type="checkbox"/> Change Plans	<input type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	


13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

ConocoPhillips Company respectfully submits the attached procedure to repair a potential casing leak and return the well to production.

Procedure attached.

SEE ATTACHED FOR  
CONDITIONS OF APPROVAL

SUBJECT TO LIKE  
APPROVAL BY STATE



14. I hereby certify that the foregoing is true and correct Name (Printed/Typed)  
Justin C. Firkins

Title Regulatory Specialist

Signature

Date 10/13/2009

**THIS SPACE FOR FEDERAL OR STATE OFFICE USE**

Approved by

*[Signature]*

DISTRICT 1 SUPERVISOR

Title

Date

NOV 09 2009

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Office

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

#### Recommended Procedure- Warren Unit 80

1. MIRU well service rig. MIRU pump truck. ND WH & NU shop tested, Class 1 Hydraulic BOP & environmental tray. Haul in 6100' +/- of 2  $\frac{3}{8}$ ", 4.7# rental workstring.
2. TOOH w/ 2  $\frac{3}{8}$ ", 4.7# IPC tubing & packer. Scan tubing while TOOH. Stand back all yellow/blue banded tubing. LD red/green band joints & replace as needed w/ new/yellow/blue banded joints.
3. TIH w/ 4  $\frac{3}{4}$ " bit & 5  $\frac{1}{2}$ " casing scraper on 2  $\frac{3}{8}$ " workstring to 5750' +/- . TOOH w/ 2  $\frac{3}{8}$ " workstring, casing scraper, & bit.
4. PU & TIH w/ 5  $\frac{1}{2}$ " RBP & 5  $\frac{1}{2}$ " treating packer on 2  $\frac{3}{8}$ " workstring to 5730' +/- . Set treating packer at 5730' +/- & **leave RBP unset**. Test casing/tubing annulus to 500 psig. If no leak is detected, go to Step # 10.
5. If leak is detected, un-set packer & set RBP at 5730' +/- . Set packer at 5715' +/- . Test RBP to 500 psig. Test casing/tubing annulus to 500 psig. If no leak is detected, go to Step # 10. If leak is detected, use RBP & packer to isolate casing leak(s) & obtain pump in rate(s) & pressure(s) for cement squeeze design.
6. If only one leak is found, contact service company for cement squeeze design. Perform cement squeeze. If multiple leaks are found in Step # 5, or a leak cannot be isolated within 30' +/- , run 40-arm caliper log based on location of leaks. Contact Production Engineer.
7. Wait on cement. RIH w/ 4  $\frac{3}{4}$ " bit & three 3  $\frac{1}{2}$ " DC's on 2  $\frac{3}{8}$ " WS. RU reverse unit & power swivel. Drill out cement retainer (if used) & cement, & clean out to RBP. Test casing & RBP to 500 psig. Resqueeze if necessary. Circulate well clean. POOH w/ 2  $\frac{3}{8}$ " workstring, DC's, & bit.
8. TIH w/ 2  $\frac{3}{8}$ " workstring & retrieve RBP. TOOH w/ RBP & 2  $\frac{3}{8}$ " workstring.
9. TIH w/ bit & bailer on 2  $\frac{3}{8}$ " workstring. Clean out to 6100' +/- . TOOH w/ bit, bailer, & 2  $\frac{3}{8}$ " workstring.
10. TIH w/ new/yellow/blue banded 2  $\frac{3}{8}$ ", 4.7# IPC tubing & set packer no shallower than 5715'.
11. Circulate wellbore w/ inhibited packer fluid. ND BOP & NU WH. RDMO well service rig. Connect surface lines. Notify NMOCD to witness mechanical integrity test. Pressure test casing to 500 psig for 30 minutes. Monitor tubing & casing pressure. Record test using circular chart. **Place an electronic copy (PDF format) of the MIT chart in the following folder on the Hobbs shared drive: HobbsOU\MIT Charts**
12. Place well on water injection. Report injection rate & injection pressure in WellView. Submit change of status report.

**Warren Unit B/T WF #80  
30-025-26642  
Conoco Phillips Company  
November 4, 2009  
Conditions of Approval**

- 1. Surface disturbance beyond the existing pad must have prior approval.**
- 2. Closed loop system required.**
- 3. 3M BOP to be NU and tested ON SITE prior to RIH.**
- 4. Subsequent sundry along with a copy of the MIT to be submitted to the BLM.**

**MAK 110409**