Form 3160-5 (August 1999)

# UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

,	FORM APPROVED			
ATT TO BE OF IN	OMB NO 1004-0135			
CORECEIVED	Expires November 30 2006			
to the same of the	anna Cural Na			


## SUNDRY NOTICES AND REPORTS ON WELLS

MAR 0 3 2010 LC061374A

Do not use this form for abandoned well Use For				6 If Indian, Allott	ee or Tribe Name
SUBMIT IN TRIPLICATE - Other instructions on reverse side		7 If Unit or CA/Agreement, Name and/or No			
1 Type of Well Oil Well X Gas Well Other 2 Name of Operator Kaiser-Francis Oil Company 3a Address		Phone No (include area		NM- 68 X 8 Well Name and Bell Lake 9 API Well No 30-025-38175	
. O. Box 21468, Tulsa, OK 74121-1468 918-4 4 Location of Well (Footage, Sec., T., R., M., or Survey Description) 1650 FSL 990 FWL NWSW(L) Sec 5 T24S R34E		918-491-4314		10 Field and Pool South Bell La 11 County or Pari Lea	
12. CHECK APPROPRIATE	BOX(ES) TO INDIC	ATE NATURE OF NO	OTICE, REPC	RT, OR OTHER	R DATA
TYPE OF SUBMISSION	TYPE OF ACTION				
X Notice of Intent Subsequent Report Final Abandonment Notice	Acidize Alter Casing Casing Repair Change Plans Convert to Injection	Deepen Fracture Treat New Construction X Plug and Abandon Plug Back	Production ( Reclamation Recomplete Temporarily Water Dispo	Abandon	Water Shut-Off Well Integrity Other
If the proposal is to deepen directionally or recompation that the Bond under which the work will be perfollowing completion of the involved operations testing has been completed. Final Abandonment determined that the final site is ready for final inspiration of the involved operations.  TD-13751' OH-13697-13751  1. CR @ 13000', sqz 135sx, WOC-72.  2. 50sx @ 13000-12770' WOC-Tag 3. 75sx @ 12515-12155' WOC-Tag 4. 50sx @ 12029-11809'  5. 50sx @ 11556-11341' 6. Perf 4-1/2" @ 10850' sqz 80sx 7. Perf 4-1/2" @ 8835' sqz 70sx 8. Perf 4-1/2" @ 7000' sqz 60sx 9. Perf 4-1/2" @ 5175' sqz 60sx 10. Perf 4-1/2" & 7" @ 3135' sqz 11. Perf 4-1/2" & 7" @ 3135' sqz 12. Perf 4-1/2" & 7" @ 789' sqz 3	rformed or provide the Bon If the operation results in a Notices shall be filed only a ection)  '  Tag  ( to 10650' WOC-Tag to 8645' WOC-Tag to 6830' WOC-Tag to 5020' WOC-Tag 75sx to 3005' WOC- 75sx to 1135' WOC-	d No. on file with BLM/Bl multiple completion or rectafter all requirements, including the second of	IA Required subsampletion in a neuding reclamation	D FOR OF APPRO	all be filed within 30 days 3160-4 shall be filed once eted, and the operator has
14 I hereby certify that the foregoing is true and correct Name (Printed/Typed) Charlotte Van Valkenburg		Title Technical (	Coordinate	or	
C. 2. 11-	Buil	Date 2/9/10		VED	<u> </u>
THIS	S SPAGE FOR PEDER		APPRO'	VEU_	
Approved by  Conditions of approval, if arry are attached Approval certify that the applicant holds legal or equitable title to which would entitle the applicant to conduct operations the second conduct operations to conduct operations to conduct operations.	EG3 of this notice does not warra those rights in the subject	Title	MAR 1 Dustin Wi	2010 Date	

Title 18 U.S.C. Section 1001, and Title 43 U.S.C. Section 1212, makes it a crime for any person knowingly and RUSBAD TIBLE OF TRUE or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction

OXY USA Inc. - Current Bell Lake #25 API No. 30-025-38175



TD-13751'

17-1/2" hole @ 739' 13-3/8" csg @ 739' w/ 1140sx-TOC-Surf-Circ

12-1/4" hole @ 5125' 9-5/8" csg @ 5125' w/ 1500sx-TOC-Surf-Circ

8-3/4" hole @ 11979' 7" csg @ 11979' w/ 1600sx-TOC-4600'-TS

6-1/8" hole @ 13697' 4-1/2" casing @ 13697' w/ 250sx-TOC-10885'-TS

3-3/4" OH @ 13697-13751

4/08-Fish @ 13042-13435' w/ CT Conn, BPV, CT Shale Washout @ 13435-13706' Fish @ 13706 w/ sub, DC, motor, mill Kaiser-Francis Oil Company NMLC-061374A: Bell Lake #25

API: 30-025-38175 Lea County, New Mexico

RE: Plugging and Abandonment Requirements, Conditions of Approval

- 1. No tag required Otherwise OK (Open Hole Fish)
- 2. OK (Cement Retainer)
- 3. Plug is optional Otherwise OK (Atoka)
- 4. WOC and tag at 11809' or shallower Otherwise OK (Casing shoe)
- 5. Plug is optional Otherwise OK (Spacer)
- 6. Cut and pull casing at approximately 10800' (Will vary based on where casing is free). Spot a plug from 10850-10640' (minimum 25sx). WOC and tag at 10640' or shallower (minimum 50' above stub). (Wolfcamp Casing stub)
- 7. Move plug to run from 8855'-8665'. (Bone Springs)
- 8. Plug is optional Otherwise OK (Spacer)
- 9. Move plug to run from 5185'-5035'. Variance on minimum 3000' based on formation. WOC and tag at 5035' or shallower. (Delaware BOS)
- 10. Change: Cut and pull casing at approximately 4500' (Will vary based on where casing is free). Spot a 150' plug (minimum 25sx) from 4550'(or 50' below cut) to 4400'. WOC and tag at 4400' or shallower (may change based on where casing is pulled from). (Stub)
- 11. Move plug to 1500-1380'. WOC and tag. (TOS)
- 12. OK (Casing shoe Surface)
- 13. Submit a subsequent report to the BLM.

See attached standard COAs.

DHW 021810

### **BUREAU OF LAND MANAGEMENT**

Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

#### Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90<sup>th</sup> day provide this office, prior to the 90<sup>th</sup> day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. In lieu of a cement plug in a cased hole, a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Any plug that requires a tag will have a minimum WOC time of 4 hours.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

- 6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). **The BLM is to be notified when the wellhead is cut off to verify that cement is to surface in the casing and all annuluses.** The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement. The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).
- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and five copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

DHW 112309



# **United States Department of the Interior**

#### **BUREAU OF LAND MANAGEMENT**

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

#### **Interim Reclamation Procedures**

**Reclamation Objective:** Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses.

Interim reclamation consists of minimizing the footprint of disturbance by reclaiming all portions of the well site not needed for production operations. The portions of the cleared well site not needed for operational and safety purposes are recontoured to a final or intermediate contour that blends with the surrounding topography as much as possible. Sufficient level area remains for setup of a workover rig and to park equipment. Topsoil is respread over areas not needed for all-weather operations. Production facilities should be clustered to maximize the opportunity for interim reclamation. In order to inspect and operate the well or complete workover operations, it may be necessary to drive, park, and operate on restored, interim vegetation within the previously disturbed area. This is generally acceptable provided damage is repaired and reclaimed following use.

To reduce final reclamation costs; maintain healthy, biologically active topsoil; and to minimize habitat, visual, and forage loss during the life of the well, all salvaged topsoil should be spread over the area of interim reclamation, rather than stockpiled.

- 1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). Interim reclamation is to be completed within 6 months of well completion.
- 3. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with interim reclamation as per approved APD or Sundry Notice. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.
- 4. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 5. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos

Supervisory Environmental Protection Specialist 575-234-5909, 575-361-2648 (Cell)

Terry Gregston Environmental Protection Specialist 575-234-5958

Bobby Ballard Environmental Protection Specialist 575-234-2230

Randy Rust Environmental Protection Specialist 575-234-5943

Linda Denniston Environmental Protection Specialist 575-234-5974

Jennifer Van Curen Environmental Protection Specialist 575-234-5905

Justin Frye Environmental Protection Specialist 575-234-5922 Cody Layton Natural Resource Specialist 575-234-5959

Trishia Bad Bear Natural Resource Specialist 575-393-3612

Todd Suter Surface Protection Specialist 575-234-5987

Doug Hoag Civil Engineering Technician 575-234-5979