State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

FILE IN TRIPLICATE OIL CONSERVATION DIVISION	
DISTRICT I 1625 N. French Dr., Hobbs, NM 88240 ECEIVED 1220 South St. Francis Dr. Santa Fe, NM 87505	WELL API NO. 30-025-28305
	5 Indicate Type of Lease
DISTRICT II 1301 W Grand Ave, Artesia, NM 88210 DISTRICT III	STATE X FEE
DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 87410	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals)	South Hobbs (G/SA) Unit
1 Type of Well: Oil Well Gas Well Other Injector	8. Well No. COOP 2
2. Name of Operator Occidental Permian Ltd.	9. OGRID No. 157984
3. Address of Operator	10. Pool name or Wildcat Hobbs (G/SA)
HCR 1 Box 90 Denver City, TX 79323 4 Well Location	
Unit Letter D . 645 Feet From The North 453 Feet From The West Line	
Section 4 Township 19-S Range 38-E	E NMPM Lea County
11. Elevation (Show whether DF, RKB, RT GR, etc.) 3620' GL	
Pit or Below-grade Tank Application or Closure	
Pit Type Depth of Ground Water Distance from nearest fresh water well Distance from nearest surface water	
Pit Liner Thickness mil Below-Grade Tank: Volume bbls; Construction Material	
12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
NOTICE OF INTENTION TO 1 SUB-	SEGUENT NEFUNTOL.
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	X ALTERING CASING
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OP	X ALTERING CASING
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OP PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN	X ALTERING CASING
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN OTHER: OTHER:	X ALTERING CASING NS. PLUG & ABANDONMENT IT JOB
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OP PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN	X ALTERING CASING NS. PLUG & ABANDONMENT IT JOB , including estimated date of starting any completion or recompletion.
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPPULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENTOTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set @ 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker with the results of the RUPU 03/25/2010. RUPU 03/25/2010	X ALTERING CASING NS. PLUG & ABANDONMENT IT JOB , including estimated date of starting any completion or recompletion.
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPPULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENTOTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set @ 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker with RDPU & RU. Clean location and return well to injection.	X ALTERING CASING NS. PLUG & ABANDONMENT IT JOB , including estimated date of starting any completion or recompletion.
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPPULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENOTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set @ 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker v. 7. RDPU & RU. Clean location and return well to injection. RUPU 03/25/2010 RDPU 03/30/2010 Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify	X ALTERING CASING NS. PLUG & ABANDONMENT IT JOB , including estimated date of starting any completion or recompletion. 4025'. w/NMOCD.
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPPULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENOTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set @ 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker v. RDPU & RU. Clean location and return well to injection. RUPU 03/25/2010 RDPU 03/30/2010 Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative.	X ALTERING CASING NS. PLUG & ABANDONMENT IT JOB , including estimated date of starting any completion or recompletion. 24025'. w/NMOCD. that any pit or below-grade tank has been/will be
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPPORTURE CASING Multiple Completion CASING TEST AND CEMENTOTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed of RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set © 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker with the result of the RDPU & RU. Clean location and return well to injection. RUPU 03/25/2010 RDPU 03/30/2010 Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or	ALTERING CASING NS. PLUG & ABANDONMENT IT JOB , including estimated date of starting any completion or recompletion. 24025'. v/NMOCD. that any pit or below-grade tank has been/will be
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPPULL OR ALTER CASING Multiple Completion CASING TEST AND CEMENOTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach, wellbore diagram of proposed of 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set @ 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker of 7. RDPU & RU. Clean location and return well to injection. RUPU 03/25/2010 RDPU 03/30/2010 Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative plan	Associate ABANDONMENT ABANDONMENT ABANDONMENT PLUG & ABANDONMENT IT JOB IT JOB IT JOB ABANDONMENT IT JOB IT
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach, wellbore diagram of proposed of 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set @ 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker v 7. RDPU & RU. Clean location and return well to injection. RUPU 03/25/2010 RDPU 03/30/2010 Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative plan SIGNATURE TITLE Administrative TYPE OR PRINT NAME Mendy Atmison E-mail address: mendy_johnson@oxy.com	Associate DATE D
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPI PULL OR ALTER CASING Multiple Completion CASING TEST AND CEMEN OTHER: 13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates proposed work) SEE RULE 1103. For Multiple Completions: Attach, wellbore diagram of proposed of 1. RUPU & RU. 2. NU BOP/ND wellhead. 3. POOH w/packer & tubing. Found wireline cutter & bars in tubing. 4. RBIH w/5-1/2" Arrowset 1-X Double Grip packer on 124 jts of 2-3/8" IPC tubing. Packer set @ 5. ND BOP/NU wellhead. 6. Test casing to 440 PSI for 30 minutes and chart for the NMOCD. Witnessed by Mark Whittaker v 7. RDPU & RU. Clean location and return well to injection. RUPU 03/25/2010 RDPU 03/30/2010 I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative plan SIGNATURE TITLE Administrative TYPE OR PRINT NAME Mendy Jumson E-mail address: mendy johnson@oxy.com	Associate ABANDONMENT ABANDONMENT ABANDONMENT PLUG & ABANDONMENT IT JOB IT JOB IT JOB ABANDONMENT IT JOB IT

