Submit 1 Copy To Appropriate District Office District I State of New Mexico Energy, Minerals and Natural Resources	Form C-103 October 13, 2009
1625 N. French Dr., Hobbs, NM 88240	WELL API NO. /
District II 1301 W. Grand Ave., Artesing NA 88210 OIL CONSERVATION DIVISION	30-025-26893 <i>V</i> 5. Indicate Type of Lease
District III 1000 Rio Brazos Rd., Aztec, NM 87410 OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Sonto Fo. NIM 87505	STATE FEE
District IV 1220 S. St. Francis Dr., Santa FANNO 6 2010	6. State Oil & Gas Lease No. L-1080
SUNDRIVE AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	7. Lease Name or Unit Agreement Name. Sawyer 4 State
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other	8. Well Number 002
2. Name of Operator	9. OGRID Number
VPR Operating LLC 3. Address of Operator	10. Pool name or Wildcat
1406 Camp Craft Road, Austin, Texas 79746	Sawyer W [SA]
4. Well Location	
Unit Letter A : 660 feet from the North line and 660 feet from the East line	
Section 4 Township 10S Range 37E NMPM County Lea	
11. Elevation (Show whether DR, RKB, RT, GR, etc.	2.)
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK ☐ ALTERING CASING ☐ TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE DRILLING OPNS.☐ P AND A ☐	
TEMPORARILY ABANDON	
DOWNHOLE COMMINGLE	
OTHER: OTHER:	П
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date	
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.	
VPR Operating proposes to Plug and Abandon this well May 08,2010 as follows:	
1] Set CIBP @ 4850' Cap w/ 35' cement. > 3/22 3/MLL 2] Perforate @ 3100'. Squeeze 25 sx plug @ 3050' - 3300'. WOC and tag. > \$POT 25' SX CMT @ 3250'	
3 Set 50 sx plug @ 2000'- 2495'> -\$ of 25 sx cm1	
4] Set 25 sx plug @ 350'-597' - 8% 5hoe - woo/149	
5] Set 25 sx plug @ surface. 6] Cut off CH.	
7] Install NMOCD approved dry hole marker.	
8] Clean and level location. Removing flowlines and tubulars.	
S-ID-	
Spud Date: Rig Release Date:	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNATURE PARE 5/6/10	
Type or print name M.Y. Merchant E-mail address: mymerch@penrocoil.com PHONE: _492-1236	
For State Use Only	
APPROVED BY: DATE 5-6-10	
Conditions of Approval (if any):	

