Submit 3 Copies To Appropriate District Office	State of New M	l exico	Form C-103
District I Energy, Minerals and Natural Resources			May 27, 2004
1625 N. French Dr., Hobbs, NM 88240 District II 1301 W Grand Ave, Artesia, NM 88210 CE CONSERVATION DIVISION		W 30	ELL API NO. / 0-025-10805
1301 W Grand Ave, Artesia, NM 88210 OFE CONSERVATION DIVISION		N DIVISION $\frac{36}{5}$.	Indicate Type of Lease
District III 1000 Rio Brazos Rd., Aztec, NM 87410N 25 2010 1220 South St. Francis Dr. Santa Fe. NM 87505		ancis Dr.	STATE FEE XX
District IV 1220 S St. Francis Dr., Santa Fe, NM		6.	State Oil & Gas Lease No.
87505 HOBBSOCD			
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			Lease Name or Unit Agreement Name
1. Type of Well: Oil Well Gas Well Other			Well Number 1
2. Name of Operator		9.	OGRID Number 141402
FULFER OIL & CATTLE LLC /			·
3. Address of Operator P.O. BOX 1224, JAL, NM 88252			D. Pool name or Wildcat NGLIE MATTIX;7R-Q-GB
4. Well Location			
Unit Letter L: 1980 feet from the SOUTH line and 660 feet from the WEST line /			
Section 20 Township 23S Range 37E NMPM LEA County			
11. Elevation (Show whether DR, RKB, RT, GR, etc.)			
	,		The state of the s
Pit or Below-grade Tank Application 🗌 or C	Closure		
Pit typeDepth to Groundwate	rDistance from nearest fresh	water well Distance	from nearest surface water
Pit Liner Thickness: mil Below-Grade Tank: Volumebbls; Construction Material			
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING			
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS P AND A			
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB			
OTHER: Isolate Jalmat Perfs and Produce Queen XX OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date			
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion			
or recompletion.			
Isolate Jalmat perforations, 3000-3097', and produce from Queen perforations, at 3500-3665'. The following procedure was discussed by Gregg Fulfer and Paul Kautz.			
Pull retrievable bridge plug. Isolate Jalmat perforations by setting a 7", 20#, AD-1 bottom packer below 3097'; set 7", 20# C-1 top pkr. above 3000'. Test pkr. Set seating nipple at 3600'. Return well to production - produce from existing Queen perforations 3500-3665'.			
Evaluate.			
I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan.			
SIGNATURE Delbu	M'Kelvy TITLE_	<u>AGENT</u>	DATE <u>6/23/10</u>
Type or print name Debbie McKe	elvey E-mail address:	Telephone No. 505-39	2-3575
ADDOLUCED BY		LE I HOTERN BHOWN	JUL 1 3 2010
APPROVED BY:	TITLE_		DATE