

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

JAN 10 2011

FORM APPROVED
OMB No. 1004-0137
Expires: July 31, 2010

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

5. Lease Serial No. NMLC063798

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE - Other instructions on page 2.

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Kaiser-Francis Oil Company

3a. Address

P. O. Box 21468, Tulsa, OK 74121-1468

3b. Phone No. (include area code)

918-491-4314

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

NW NE (660' FNL & 1980' FEL) Sec. 12-24S-33E

7. If Unit of CA/Agreement, Name and/or No.

Bell Lake Unit

8. Well Name and No.

Bell Lake #19

9. API Well No.

30-025-26257

10. Field and Pool or Exploratory Area

S. Bell Lake (Delaware)

11. Country or Parish, State

Lea/NM

12. CHECK THE APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

☒ Notice of Intent☐ Subsequent Report☐ Final Abandonment Notice☐ Acidize☐ Alter Casing☐ Casing Repair☐ Change Plans☐ Convert to Injection☐ Deepen☐ Fracture Treat☐ New Construction☒ Plug and Abandon☐ Plug Back☐ Production (Start/Resume)☐ Reclamation☐ Recomplete☐ Temporarily Abandon☐ Water Disposal☐ Water Shut-Off☐ Well Integrity☐ Other

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

Please see attached proposed procedure.& wellbore diagram.

Approximate starting date: 2/15/11.

SEE ATTACHED FOR
CONDITIONS OF APPROVALRECLAMATION PROCEDURE
ATTACHED

14. I hereby certify that the foregoing is true and correct. Name (Printed/Typed)

Charlotte Van Valkenburg

Title Technical Coordinator

Signature

Date 12/29/10

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by

Title

JAN 6 2011

Date

Office

/s/ Dustin Winkler

BUREAU OF LAND MANAGEMENT
CARLSBAD FIELD OFFICE

Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

Kaiser-Francis Oil Company

South Bell Lake Unit #19

660' FNL, 1980' FEL
Section 12, T24S, R33E
Lea County, New Mexico
API # 30-025-26257

WELL DATA

TD: 14,760'
PBSD: 8100' estimated, plugged back with multiple cement retainers and cast iron bridge plugs.

Elevation: GL Elev. = 3625'
KB Elev. = 3649'

Surface Casing: 16" 65# H40 @ 700' cemented w/ 575 sx, circ.

Intermediate Csg: 10-3/4" 45.5# K55 @ 5245' cemented stg 1 w/ 1400 sx, stg 2 through DV tool @ 3000' w/ 1700 sx. TOC @ 1280' by temp svy.

Production Csg: 7-5/8" 33.7# N80 @ 13,000' cemented w/ 955 sx, TOC @ 8560'.

Production Liner: 5" 18# N80 from 12,424' – 14,758', cemented w/ 400 sx, TOC @ 12,424'.

Tubing: 8000' of 2-7/8" 6.5# N80 EUE with SN and 4' bull plugged perf sub on bottom.

Tubular Specs:					100%	80%	Tensile
Item	ID	Drift	Bbl/ft	Gal/ft	Burst	Burst	Yield
10-3/4" 45.5# K55	9.950	9.794	.09617	4.0393	3580	2864	528,000
7-5/8" 33.7# N80	6.756	6.640	.04445	1.8672	7900	6320	674,000
2-7/8" 6.5# N80	2.441	2.347	.00579	0.2431	10500	8400	144,960

PROCEDURE

- 1) MIRU PU. ND WH, NU BOP. Take delivery of 200' of 2-7/8" tbgr. TIH and tag PBSD, report to Tulsa if PBSD varies by more than 100' from reported depth of 8100'. Circulate hole w/ 9ppg plug mud through tbgr. POOH LD tbgr. Verify approx. PBSD with joint count.

- 2) RU WL. Free point and cut off 7-5/8" csg. RU csg crew and LD 7-5/8" csg.
- 3) RU WL. RIH w/ 10-3/4" CIBP and set @ 5100'. Dump 50' of cement on top. RIH w/ 4" casing gun and perforate cement holes from 1200' – 1202' (4 spf, 8 large diameter holes). RD WL.
- 4) Load 10-3/4" csg and establish circ out 10-3/4" x 16" bradenhead. Cement down 10-3/4" while taking returns at surface with 130 bbls of filler cement and 120 bbls of 50/50 poz or equiv. Drop wiper plug and displace cmt with plug mud. When 85 bbls of displacement has been pumped, close bradenhead and pump an additional 10 bbls at 1 bpm. SI well leaving top of cement inside 10-3/4" @ +/- 1000'. WOC.
- 5) After cmt has set, GIH w/ bailer and tag plug. POOH. Spot surface cmt plug from 50' – 4'. Cut off csg below GL and weld on cap. Restore location.


WELL DIAGRAM - (11-23-10)

BELL LAKE UNIT #19

660' FNL & 1980' FEL

SECTION 12-24S-33E

LEA COUNTY, NM



SPUD: 3-25-79 COMP: 9-14-79 TD: 14,760' PBD: 14,473' GR: 3625'
API# 30-025-26257

COMPLETION:

PF: 14,326-38'

A w/2500 g 6% Hcl 1.5% HF w/flouro surfactant; 148,000 SCFN2

PF: 14,326-354'

Frac w/8000 g methanol; 8000 g liquid CO2

WO: 10/80: Jetted w/CT & N2, flw'd 94 MCFD

WO: 9/81: TA well - RIH w/2.343 GR. Cud not get past 13,780'. RIH w/1-1/2\" sinker bar cud not get past 13,897'. Salt/sd in jars. Pmp 40 bbls FW. Press to 6000#. Tbg plugged RIH w/1-3/4\" bailer to 14,140'. Run 2.343 GR. Hit many obstructions. Stuck @ 1004'. RIH w/2.34 broach to 13,770' got stuck. Jarred loose. Rec'd pieces of plastic coating. RDMO.

WO: 1/92: RIH w/1-7/16\" sinker bar to 14,114'. RIH w/2.03 SB to 14,001'. Stuck at 13,875'. Work free. POOH. RDMO.

WO: 4/92: RH to 14,146', raise to 14,113', shoot 6 holes in tbg w/1-3/8\" tbg punch. Attempt to release from pkr, FP shows tbg stuck @ 12,380', RIH w/tbg CIBP (1.906') set @ 14,000'. Shot off tbg @ 12,335'. Cud not pull shot tbg @ 12,000'. Cud not pull tbg. Shot tbg @ 11,990'. POOH w/tbg. RIH w/6.343\" GR to 11,900'. Set CIBP @ 11,400'. Dump cmt on top to 11,350'.

WO: 07/06: TEST BONE SPRINGS

Found mud in hole and gas pressure (leaking CIBP???)

Set CIBP 9568' w/20' cmt on top. Circ hole clean.

PF: BONE SPRINGS: 9001-2; 7-10; 13-16; 20-24; 27-28; 35; 38; 41-43 (1spf)
Acid w/1500 gal 15% NEFE. Swab test. Some oil. Mostly water.

Set retainer 8995'. Sqz w/200 sxs

PF: BONE SPRINGS: 8941; 44; 45; 62; 63; 64; 66; 67; 68; 70; 72; 75; 76; 78
Acid w/1500 gal 15% NEFE. Swab test. Some water. No Oil Sho.

3/22/10: Perf Bell Lake sd- 8532-40', prod wtr. Sqzd and reperf, still prod wtr. Set cmt retainer @ 8502' & sqz w/ 100 sx. Perf U. Bell Lake, 8410-50'. Set CIBP @ 8380' w/ 35 sx cmt on top. Perf Cherry Canyon 8160-68'. Set CIBP @ 8135' w/ 35 sx cmt on top. Test 7-5/8\" csg to 1500#. Left well SI w/ tbg in hole.

TD 14,760'

Kaiser-Francis Oil Company
NMLC-063798: Bell Lake #19
API: 30-025-26257
Lea County, New Mexico

RE: Plugging and Abandonment Requirements, Conditions of Approval

1. OK
2. Stubs require a plug spotted 50' below cut. Spot a plug (approx 70sx) from 50' in the plug to 120' out of the stub. WOC and tag to verify. (Stub)
3. Change: Instead of the proposed CIBP, a plug is to be spotted from 5295'-5145' (approx 65sx). WOC and tag at 5145' or shallower – Otherwise OK
(Casing shoe – Delaware – BOS)
If the stub is at or above the casing shoe, contact the BLM for changes to the plugging procedure.
- 3a. Spot a plug from 1585'-1465' (approx 50sx). WOC and tag at 1465' or shallower (TOS)
4. Tag at 1000' or shallower. If circulation cannot be achieved, contact the BLM –
Otherwise OK
- 4a. Spot a plug from 750'-640' (approx 45sx). WOC and tag at 640' or shallower
(Casing shoe)
5. Surface plug to be a minimum of 60'. Verify cement to surface in all annuluses –
Otherwise OK (Surface)
6. Submit a subsequent report to the BLM.

H₂S monitoring equipment shall be on location.

See attached standard COAs.

DHW 010611

BUREAU OF LAND MANAGEMENT

**Carlsbad Field Office
620 East Greene Street
Carlsbad, New Mexico 88220
575-234-5972**

**Permanent Abandonment of Federal Wells
Conditions of Approval**

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within **ninety (90)** days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

2. **Notification:** Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.

3. **Blowout Preventers:** A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. **Mud Requirement:** Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.

5. **Cement Requirement:** Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. **Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.**

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Dry Hole Marker: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). **The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.**

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

7. Subsequent Plugging Reporting: Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**

8. Trash: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

DHW 122010



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office
620 E. Greene St.
Carlsbad, New Mexico 88220-6292
www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.

2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.
5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos
Supervisory Environmental Protection Specialist
575-234-5909, 575-361-2648 (Cell)

Cody Layton
Natural Resource Specialist
575-234-5959

Terry Gregston
Environmental Protection Specialist
575-234-5958

Trishia Bad Bear
Natural Resource Specialist
575-393-3612

Bobby Ballard
Environmental Protection Specialist
575-234-2230

Todd Suter
Surface Protection Specialist
575-234-5987

Randy Rust
Natural Resource Specialist
575-234-5943

Doug Hoag
Civil Engineering Technician
575-234-5979

Linda Denniston
Environmental Protection Specialist
575-234-5974

Tanner Nygren
Natural Resource Specialist
575-234-5975

Jennifer Van Curen
Environmental Protection Specialist
575-234-5905

John Fast
Natural Resource Specialist
575-234-5996

Justin Frye
Environmental Protection Specialist
575-234-5922