

Submit 3 Copies To Appropriate District Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised June 10, 2003

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-005-20495
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Robert H. Hannifin
8. Well Number #1
9. OGRID Number 009974
10. Pool name or Wildcat Wildcat San Andres

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

HANSON OPERATING COMPANY, INC.

3. Address of Operator

P. O. Box 1515, Roswell, New Mexico 88202-1515

4. Well Location

Unit Letter C : 660 feet from the North line and 1980 feet from the West line

Section 31 Township 9 South Range 30 East NMPM Chaves County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
4010' GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Hanson Operating Company, Inc. requests approval to plug and abandon the well in the following manner:

1. TIH with tubing to 3300'. Spot 25 sack cement plug at 3300'. WOC. Tag.
2. Displace with 12.5 PPB gelled brine water. Tag top of cement at or above 3232'.
3. Perf and squeeze 25 sack cement plug at 1437'. WOC. Tag top of cement at 1387' maximum.
4. Perf and squeeze 25 sack cement plug at 350'. WOC. Tag top of cement.
5. Perf and circulate 25 sack cement plug at 60' to Surface.
6. Set Dry Hole Marker.
7. Reclaim and finalize location.

Verbal approval granted by Billy Prichard, OCD Hobbs.

THE COMMISSION MUST BE NOTIFIED 30 DAYS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Carol J. Garcia TITLE Production Analyst DATE 02/02/2004

Type or print name Carol J. Garcia E-mail address: hanson@dfn.com Telephone No. 505-622-7330

(This space for State use)

APPROVED BY [Signature] TITLE PETROLEUM ENGINEER DATE MAR 02 2004  
Conditions of approval, if any: