

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Ave., Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

OIL CONSERVATION DIVISION
1020 South St. Francis Dr.
Santa Fe, NM 87505

October 13, 2009

WELL API NO. 30-041-10008
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Milnesand Unit
8. Well Number 142
9. OGRID Number 257420
10. Pool name or Wildcat Milnesand, San Andres

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator
EOR Operating Company

3. Address of Operator
200 N. Loraine, Suite 1440 Midland, TX 79701

4. Well Location
Unit Letter L : 1980 feet from the S line and 660 feet from the W line
Section 12 Township 08S Range 34E NMPM County Roosevelt

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER:	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOR Operating requests approval to plug and abandon this well according to attached proposed procedure and wellbore diagram.

Est. start date 6/2/11

EOR will notify OCD 24 hours prior to the beginning of plugging operations.

**Note: EOR plans to use BCM & Associates to plug a total of 12 wells. EOR has scheduled to complete these 12 P&As prior to 6/30/11.

The Oil Conservation Division Must be notified
24 hours prior to the beginning of plugging operations.

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jana True TITLE Production Asst. DATE 4/28/11

Type or print name Jana True E-mail address: jtrue@enhancedoilres.com PHONE: 432-687-0303

For State Use Only

APPROVED BY: [Signature] TITLE STATE MGR DATE 5-5-2011

Conditions of Approval (if any):

Plugging Procedure

Milnesand Unit #142

API No. – 30-041-10008

1. Prepare location and test anchors
2. MIRU plugging rig
3. Notify OCD/HFO 24 hours prior to commencement of P & A procedure.
4. NDWH/NU BOP
5. RIH w/4 ½ CIBP on 2 3/8 WS @ 4540' (+/-) – within 100' of top perf – 4596'
 - a. Spot ~~35~~ ^{25SX} of cement on CIBP ~~25SX~~.
 - b. Let cement cure – bump plug @ 4505' (+/-)
6. Load well with plugging mud and conduct MIT to 500 psi. , test for leak off.
 - a. Bleed pressure off after MIT.
7. ~~TIH to 4505' and spot 25 SX cement plug~~
 - a. ~~Wait on cement and tag~~
8. MIRU WL and RIH w/perf gun to 3005'
 - a. perforate @ 2 JSPF
 - b. POOH w/WL
 - c. Rig WL down move off loc.
9. TIH w/WS – ~~spot~~ ²⁵ 25 SX cement plug @ 3005'
 - a. Wait on cement
 - b. Tag plug
10. MIRU WL and RIH w/perf gun to 1505'
 - a. perforate @ 2 JSPF
 - b. POOH w/WL
 - c. Rig WL down move off loc.
11. TIH w/WS – ~~spot~~ ²⁵ 25 SX cement plug @ 1505'
 - a. Wait on cement
 - b. Tag plug
12. MIRU WL and RIH w/perf gun to ~~130~~ ⁴⁴⁵ 445'
 - a. perforate @ 2 JSPF
 - b. POOH w/WL
 - c. Rig WL down move off loc.
13. ~~TIH w/WS – spot 25 SX cement plug @ 420'~~
 - a. ~~8 5/8 csng. Shoe @ 391'~~
 - b. ~~Wait on cement~~
 - c. ~~Tag plug~~
14. ~~TIH to tag plug @ 370' (+/-)~~
 - a. ~~Spot cement plug~~
 - b. circulate cement to surface ✓
 - c. TOH w/WS
15. RDMO Plugging Rig
 - a. Install P & A marker plate
 - b. Cut off dead men
 - c. Remediate Location

