Form 3160-5 (November 1994)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB No. 1004-0135 Expires July 31, 1996

NM-04242

5. Lease Serial No.

6. If Indian, Allottee or Tribe Name


SUNDRY NOTICES AND REPORTS ON WELLS


Do not use this form for proposals to drill or reanter an

abandoned well. Use Form 3160-3 (APD) for such propositive					A/A
SUBMIT IN TRIPLI	CATE – Other instru	ctions on revers	e side	7. If Unit or Ca	A/Agreement, Name and/or No.
1. Type of Well				8. Well Name	and No
X Oil Well Gas Well Other				DENIUS FEDERAL #4	
2. Name of Operator			9. API Well N		
LIME ROCK RESOURCES		3b. Phone No. (include	le area code)	-	30-025-01404
3a. Address c/o Mike Pippin LL	505-327-4573		10. Field and Pool, or Exploratory Area		
3104 N. Sullivan, Farmingtor 4. Location of Well (Footage, Sec., T			Corbin Abo (13150)		
	/	•		AND	
1980' FSL & 330' FWL Unit L Sec. 34, T17S, R33E			Lea County, New Mexico		
12. CHECK APPROPRIATE BOX	(ES) TO INDICATE NAT	URE OF NOTICE, RE	PORT, OR OTI	IER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION				
X Notice of Intent Subsequent Report	Acidize Alter Casing Casing Repair	Deepen Fracture Treat New Construction	Reclamati	plete Other	
	Change Plans	Plug and Abandon	Temporar	ily Abandon	
Final Abandonment Notice 13. Describe Proposed or Completed Operation	Convert to Injection	Plug Back		-	por avingte duration thereof.
Tag top of plug. Perf 8-5/8" cs flange. Install P&A marker with RECLAMAT	is Abo well as follows: Mooth inside & outside csg e csg & 8 sx inside csg to w/ 2 SQ holes & SQ w/38 ag top of plug. Cut off 4-csg to place cmt both ins 35 sx cmt outside csg & c @ 60' & circ (~38 sx) c	o place cmt both inside sx cmt outside csg -1/2" csg @ 1500' & side & outside csg fro 31 sx inside csg to plant down csg & out b	csg @ 5650". WOC. Tag to the & outside cs & 15 sx inside TOH. Perf 8-5 m 1300' to 12 ace cmt both it radenhead val	ing from 4900' to cog to place or place or place or place or place or place or place. The place of the place	o 4800'. WOC. Tag top of mt both inside & outside csg 0' w/ 2 SQ holes & SQ w/35 sx ag top of plug. Perf 8-5/8" csg e csg from 350' to 250'. WOC. & cut off csg below surface csg
14. I hereby certify that the foregoing	g is true and correct	Leval			
Name (Printed/Typed) Mike	Title Petroleum Engineer (Agent)				
Signature	Date				
This	otissin			May 5, 201	
	THIS SP	ACE FOR FEDERAL C	K STATE USE	Date	
Approved by Lames U	las	Title SEP	15	Date	5.28-11
Conditions of approval, if any, are attached critify that the applicant holds legal or exhibit would entitle the applicant to condititle 18 U.S.C. Section 1001, makes in	quitable trie to mose ngms in the	Subject rease CFC		nt or agency of the	United States any false, fictitious or

fraudulent statements or representations as to any matter within its jurisdiction.

JUN 1 0 2011





Elevation	n: 4,1	114' GL			
Date Spud: 08/14/60		08/14/60			
Date TD'd: 09/25/60		09/25/60			
Date Completed: 10/13/60					
Zone		<u>Frac</u>			
Abo	1,0	1,000 gals 15% HCl & 2,000 gals MOD-202			
Abo 1,500 gals 15% CRA					
Abo	Abo 500 gais 20% HCI				
Recompletions & Workovers					
Date					
06/08/6	9	Installed gas lift valves.			
02/02/7	4	Acidized w/ 1,500 gals 15% CRA			
06/04/7	4	Pulled and replaced 7,100' of 4-1/2" casing. Squeezed perfs @ 8,673-74' w/ 150 sxs			
09/28/7	4	Squeezed casing leak 7,136-48' w/ 200 sxs. Acidized w/ 1,000 gals 15% HCI & 2,000 gals MOD-202			
07/31/7	75	Installed submersible pump.			
09/15/7	 75	Replaced submersible pump with rod pump installation.			
05/07/7	77	Squeezed casing leak 5,244' w/ 150 sxs			
04/81		Swedged out tight spot in casing 5,659'			
06/09/8	31	Squeezed casing leak 5,614' w/ 150 sxs			
04/01/8	B5	Replaced rod string due to excessive parts.			
02/19/	88	Repaired parted tubing and replaced 21 joints			
04/19/	91	Repaired parted tubing and replaced 180 joints			
04/01/	92	Repaired parted tubing			
04/24/	96	Replaced rod string			
07/06/	96	Repaired parted casing @ 594'			
02/15/	05	Replaced rod string.			
05/12/	06	Possible casing leak noted.			
03/02/	/09	Parted rods. Top of fish inside tubing @ 5,944'. Unable to unseat pump. Unable to pull tubing. Casing standing full – potential hole in casing or collapsed casing.			
06/22	/09	Chemically cut tubing @ 5,922'. Ran CBL which showed TOC @ 4,950'. Ran tubing back in well. Well TA'd.			
Last Well Test: 16 BOPD, 100 BWPD, 30 MCFPD					
<u></u>					

PBTD @ 9,098'

4-1/2"; 11.6#; J-55; ST&C Casing @ 9,124'

TD @ 9,125'

Lime Rock Resources
Denius Federal 4
Sec 34-17S-33E
Lea County, NM
Updated: 22 June 2009 SJH

sources should be to be the women solution splanes marries visities to the contract of the con OG LS# NM 108507

NW 801

Comments of the control of the contr

NW 108507

OC AN MIR 830231 Appendix system operation operations of the control of the control operation operation of the control operation of the control operation of the control operation operation operation of the control operation oper

showny.

ypithelin yesigalis typisma gyjutud Vergan talanis adelese sastanis

garrin gibose nombor applits

1202800

895695 Willy My Della

CC 062391

BULBOLL

MIN TO BY

_

Lime Rock Resources A, L. P. 3104 N. Sullivan Farmington, NM 87401

RE:

NMNM99146; Denius Federal No. 4 1980' FSL & 330' FWL, Sec. 34, T17S-R33E Lea County, New Mexico

Abandonment Conditions of Approval;

Set a packer just above the top of fish and try to establish an injection rate. If you can establish a rate, pump an adequate amount of cement to fill the wellbore to 50' above the top of fish. WOC and tag. If an injection rate can't be established, continue as per Conditions of Approval.

Perforate the 4-1/2" casing @ 5650' and squeeze with adequate cement to fill from 5650' – 5500' (25 sack minimum). WOC and tag no lower than 5500'.

Perforate the 4-1/2" casing @ 4900' and squeeze with adequate cement to fill from 4900' -4750' (25 sack minimum). WOC and tag no lower than 4750'.

8-5/8" shoe plug is OK as is. Note: If you are going to cut and pull 4-1/2" casing @ 1500', you might consider cutting below the 8-5/8" shoe and pull, then setting a stub plug from 50' inside the stub to extend 50' into the 8-5/8" casing. Otherwise, you will need to set a stub plug at 1550' - 1450' (25 sack minimum), WOC and tag no lower than 1450.

The remaining procedure is OK as is.

If you have questions, please contact Jim Amos at 505-234-5909.

J. Amos 5/28/11

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

J. Amos 3/6/11



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, redistribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- 1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Environmental Protection Specialist 575-234-5909, 575-361-2648 (Cell)

Terry Gregston
Environmental Protection Specialist
575-234-5958

Bobby Ballard Environmental Protection Specialist 575-234-2230

Randy Rust Environmental Protection Specialist 575-234-5943

Linda Denniston Environmental Protection Specialist 575-234-5974

Jennifer Van Curen Environmental Protection Specialist 575-234-5905

Justin Frye Environmental Protection Specialist 575-234-5922 Cody Layton Natural Resource Specialist 575-234-5959

Trishia Bad Bear Natural Resource Specialist 575-393-3612

Todd Suter Surface Protection Specialist 575-234-5987

Doug Hoag Civil Engineering Technician 575-234-5979