

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator <u>The Wil-Mc Oil Corporation</u>		8. Farm or Lease Name <u>White State</u>
3. Address of Operator <u>Drawer 1889, Midland, Texas 79701</u>		9. Well No. <u>1-4</u>
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>East</u> LINE AND <u>660</u> FEET FROM THE <u>North</u> LINE, SECTION <u>15</u> TOWNSHIP <u>10S</u> RANGE <u>32E</u> NMPM.		10. Field and Pool, or Wildcat <u>Mescalero</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>4328' Gr.</u>		12. County <u>Lea</u>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP at 8500' and dump 4 sacks cement on top of bridge plug.
2. Shoot off 4 1/2" casing at free point and lay down casing.
3. Run tubing and displace hole with 25 lbs./bbl. mud to 4 1/2" casing stub.
4. Spot 100' cement plug over 4 1/2" casing stub.
5. If Glorieta is exposed (4833'-4933'), displace hole with mud to top of Glorieta and spot 100' cement plug at top of Glorieta.
6. Pull tubing to intermediate casing shoe at 3516' and displace hole with mud.
7. Spot 100' cement plug over intermediate casing shoe.
8. Finish displacing hole with mud and cap with 10 sacks cement.
9. Install marker, clean, and level location.

Anticipate this work will begin about 10-20-73, depending upon availability of plugger.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jm Kulpatich TITLE Engineer DATE 10-9-73

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

THE COMMISSION MUST BE NOTIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLUGGING OPERATIONS FOR THE C-103
TO BE APPROVED.