

DATE RECEIVED		
REVISION		
FE		
AS.		
OFFICE		
RATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes C-101
C-102 and C-103
Effective 1-1-61

<p>SUNDRY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.</p>		<p>5a. Indicate Type of Well State <input checked="" type="checkbox"/> <input type="checkbox"/></p> <p>5. State Oil & Gas Lease No. B-9596</p>
<p>6. Well <input checked="" type="checkbox"/> WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-</p>		<p>7. Unit Agreement Date</p>
<p>8. Name of Operator Amerada Hess Corporation</p>		<p>8. Farm or Lease Name State X "A"</p>
<p>9. Address of Operator Drawer "D", Monument, New Mexico 88265</p>		<p>9. Well No. 1</p>
<p>10. Location of Well UNIT LETTER <u>M</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>24</u> TOWNSHIP <u>11-S</u> RANGE <u>32-E</u> NMPM.</p>		<p>10. Field and Pool, or Name of Moore - Devonian</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 4341' DF</p>		<p>12. County Lea</p>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

10,700' TD
10,440' DOD
Csg. Perfs. 10,417' to 10,423'
13-3/8" Csg. set @ 300' - Cement Circ.
8-5/8" Csg. set @ 3470' - T. cement 538'
5-1/2" Csg. set @ 10,700' - T. Cement 7393'

Plan to: Set BP at 10,000' with 35' cement on top. Cut 5-1/2" casing at 7000'.
Spot 75 sx. cement plug in top of 5-1/2" casing. Spot 35' sx. cement
plug in bottom of 8-5/8" casing. Spot 10 ft. cement plug at surface
with permanent dry hole marker. Mud will be spotted between all plugs.
Plug and abandon.

* 100' plug top of Casing.

** 100' plug in Vent Shoe 8 5/8

mud between all plugs - 2584/100 bbls brine

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED M. D. Black TITLE Superv., Admin. Services DATE 4-18-74

APPROVED BY Lee C. H. H. TITLE Chief Geol. DATE
CONDITIONS OF APPROVAL, IF ANY: