

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
L - 1912

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator I. W. Lovelady	8. Farm or Lease Name Elk State
3. Address of Operator 406 N. Marienfeld, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER I 330 FEET FROM THE east LINE AND 1980 FEET FROM THE south LINE, SECTION 10 TOWNSHIP 12S RANGE 32E NMPM.	10. Field and Pool, or Wildcat E. Carrock Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4415 DF	12. County Lea

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUS AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUS AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

Note: Last production, well was pumping 2 bbls. oil and 6 bbls. water per day with 25 MCF gas per day.

- We intend to:
1. Load 4½" csg. with mud @ 25 sx. per 100 bbls. water and pull out with tubing.
  2. Set cast iron bridge plug on wire line and cap with 35' cement.
  3. Run free point and cut casing off with wireline.
  4. Spot 100' cement plugs through 4½" casing @
    - a. Top of 4½" stub.
    - b. Top of Glorietta @ 5050'.
    - c. In and out of 8 5/8" shoe @ 3655'.
    - d. Above 8 5/8" stub @ 604'.
    - e. In and out of 13 3/8" shoe @ 297'. Pull out with all 4½" casing.
  5. Put 10 sx. in top and install marker.
  6. Clean up location.

24 hr. notice

We intend to start operations as soon as a rig is available.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. L. Hamm Jr. TITLE Prod. Supt. DATE 8-28-73

APPROVED BY Joe D. Ramsey TITLE Dist. I, Supv. DATE AUG 30 1973

CONDITIONS OF APPROVAL, IF ANY