

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E9035
7. Unit Agreement Name
8. Farm or Lease Name Humble State
9. Well No. 2
10. Field and Pool, or Wildcat Inbe Permo Penn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator KKA Corporation
3. Address of Operator 405 Wall Towers East - Midland, Texas 79701
4. Location of Well UNIT LETTER <u>G</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>2080</u> FEET FROM THE <u>East</u> LINE, SECTION <u>26</u> TOWNSHIP <u>10S</u> RANGE <u>33E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4202 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plugging Procedure:

1. Set 100' plug @9700' - Fill hole w/gel laden fluid. Perf. @9743 - 9745.
2. Cut 4 1/2" csg. off.
3. Set 100' plug @4 1/2" csg. stub.
4. Set 100' plug @5350' if csg. is cut below.
5. Set 100' plug @3963' bottom of 8-5/8" csg.
6. Cut 8-5/8" csg. off - set 100' plug @ stub.
7. Set 100' plug @320' - Base of surface csg.
8. Set 10 sk plug in top of 13-3/8" csg.; set marker & clean up location.

→ Set 100' plug at base of salt if not behind 8 5/8"

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Garin Godwin</u>	TITLE <u>Agent</u>	DATE <u>11-9-72</u>
APPROVED BY <u>John Runyan</u>	TITLE <u>Geologist</u>	DATE <u>NOV 13 1972</u>

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

1 - 1012

OIL CONSERVATION COMM.
BUREAU, W. M.