

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
<b>E9035</b>	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator <b>KKA Corporation</b>		8. Farm or Lease Name <b>New Mex. "BQ" State</b>
3. Address of Operator <b>405 Wall Towers East - Midland, Tx. 797011</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>L</b> , <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>West</b> LINE, SECTION <b>26</b> TOWNSHIP <b>10-S</b> RANGE <b>33-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Inbe-Pennsylvanian</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4208 DF</b>		12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐

OTHER ☐

PLUG AND ABANDON ☒

CHANGE PLANS ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

COMMENCE DRILLING OPNS. ☐

CASING TEST AND CEMENT .QB ☐

OTHER ☐

ALTERING CASING ☐

PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### Plugging Procedure:

1. Set 25 sk. @9700' - Perf. 9728'-9734'. Fill hole w/mud laden fluid. *25 sks / bbl*
2. Top of cement behind 4 1/2" csg. @6000'.
3. Cut off 4 1/2" csg. & pull csg.
4. Set 30 sx. cement plug @ top of 4 1/2" stub.
5. Set 30 sk. cement plug @5300' on top of Glorieta.
6. Set 30 sk. cement plug @4040' in and out bottom of 8-5/8" csg. *no plug*
7. Pull 8-5/8" csg. from 1200'; set 55 sk. plug @ stub.
8. Set 55 sx. plug @ base of surface csg. @345'.
9. Set 10 sx. plug in top of 13-3/8" csg.; set marker & clean up location.

*24 hr. notice*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *Paul Lewis* TITLE *Prod. Foreman* DATE *7-16-73*

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: