

MAR 13 1970

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. NM 211

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Texas Pacific Oil Company, Inc. 3. Address of Operator P. O. Box 1069, Hobbs, New Mexico 4. Location of Well UNIT LETTER C , 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 2 TOWNSHIP 12-S RANGE 33-E NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) 4237' GR	7. Unit Agreement Name 8. Farm or Lease Name State "C" A/c-1 9. Well No. 5 10. Field and Pool, or Wildcat North Bagley Lower Penn 12. County Lea
--	--

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Install B.O.P.
2. Drill out CIBP at 8970' and 8996' - Rub tubing with cement retainer at 8940' and squeeze with 100 sacks incor. Reverse out, Pull tubing, Drill out cement and test.
3. Drill out CIBP at 9044' and run bit to 9900'.
4. Set retainer at 9280' and squeeze perfs 9306 - 9326' with 100 sacks incor. Drill out and tst.
5. Perf 9730 - 9855' (22 holes)
6. Run packer and acidize with 5000 gal 15% N.E.
7. Swab back load and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed by

SIGNED Sheldon Ward	TITLE Area Superintendent	DATE March 12, 1970
APPROVED BY	TITLE SU	DATE MAR 16 1970
CONDITIONS OF APPROVAL, IF ANY:		