

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION  
HOLDINGS OF THE N.M.O.C.C.

JUL 20 11 59 AM '67

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E - 2064	
7. Unit Agreement Name -	
8. Farm or Lease Name South Four Lakes Unit	
9. Well No. 7	
10. Field and Pool, or Wildcat Four Lakes Penn	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Humble Oil & Refining Company
3. Address of Operator P. O. Box 1600, Midland, Texas 79701
4. Location of Well UNIT LETTER I, 1980 FEET FROM THE S LINE AND 660 FEET FROM THE E LINE, SECTION 35 TOWNSHIP 11-S RANGE 34-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4160 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Request permission to plug and abandon well in following manner:  
Cut off 4½" csg. @ approximately 8650' and recover, cut off 8-5/8" casing @ approximately 2450' and recover. Pull retrievable bridge plug @ 10053'. Hole to be filled w/mud laden fluid. Set plug # 1 from 10,370 - 10,170 w/16 sx. neat cmt.  
Set plug # 2 from 10,000 - 9,750 w/20 sx. neat cmt.  
Set plug # 3 from 8,750 - 8,550 w/40 sx. or across 4½" csg. cmt.  
Set plug # 4 from 7,800 - 7,700 w/30 sx neat cmt.  
Set plug # 5 from 4,250 - 4,150 w/30 sx. neat cmt.  
Set plug # 6 from 2,500 - 2,400 w/45 sx or across 8-5/8" csg. cmt.  
Set plug # 7 from 2,080 - 1,980 w/60 sx. neat cmt.  
Set plug # 8 from 450 - 350 w/70 sx. neat cmt.  
Set plug # 9 from 20 - surface w/15 sx. neat cmt.

Install dry hole marker & clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. T. Burns TITLE Agent DATE 7-18-67  
APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY: