

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

HOBBS OFFICE O. C. C.  
MAR 27 7 50 AM '67

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

6. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name Lea State	
9. Well No. 2	
10. Field and Pool, or Wildcat Allison-Penn	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Coastal States Gas Producing Company
3. Address of Operator P. O. Box 235, Midland, Texas 79701	4. Location of Well UNIT LETTER D 768 FEET FROM THE north LINE AND 766 FEET FROM THE west LINE, SECTION 2 TOWNSHIP 9S RANGE 36E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4060.90' GL	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Casing set as follows:

Size	Wt.	Grade	Set at:
13-3/8"	54.5#	J-55	366'
8-5/8"	32.0#	J-55	4140'
5-1/2"	17.0#	J-55	4012' - 9784' (liner)
		N-80	

1. Pull and recover 2-1/2" and 3" tubing.
2. Cut liner hanger and attempt to recover 5-1/2" liner from approximately 4025' to 8050'.
3. Fill hole with drilling fluid and spot cement plugs as follows:

- 3.1 25 sx at perms 9759-63'
- 3.2 25 sx at casing stub (approximately 8050')
- 3.3 25 sx at 6960' (Tubb)
- 3.4 25 sx at 5540' (Glorietta)
- 3.5 25 sx at bottom of 8-5/8"-4140'
- 3.6 10 sx at surface

4. Cut off casing; weld steel plate on top; install marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe R. Hume TITLE Div. Prod. Supt. DATE March 24, 1967

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: