

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION, C. O.

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

3-MOCC
1-File
1-C. H. Brockett, Inc.
Box 1005, Midland, Texas

MAY 18 11 00 AM '66

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Tidewater Oil Company	8. Farm or Lease Name O. K. Lovejoy
3. Address of Operator Box 249, Hobbs, New Mexico	9. Well No. 2
4. Location of Well UNIT LETTER F , 1830 FEET FROM THE North LINE AND 1980 FEET FROM THE WEST LINE, SECTION 14 TOWNSHIP 9 S RANGE 36 E NMPM.	10. Field and Pool, or Wildcat Allison-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4048 GL	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- It is proposed to plug and abandon this well as follows:

Run 2-1/2" tubing to top of Baker Model D packer at 9686'. Lay 25 sk cement plug on top of Model D packer. Shoot off and pull 5-1/2" casing at lowest free point. Lay 25 sk plugs across top of 5-1/2" casing and tops of Abo, Tubb and Glorieta formations. Lay 25 sack plug across bottom of 8-5/8" casing at 4310'. Lay 10 sack cement plug in top of 8-5/8" casing. Install dry hole marker. Mud laden fluid to be left between all plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed By:

SIGNED B. M. BREINING TITLE Area Engineer DATE 5-17-66

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: