

COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS <small>DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.</small>		
1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- Temporarily Abandoned		7. Unit Agreement Name
2. Name of Operator Oil Development Company of Texas		8. Farm or Lease Name SFPRR 23
3. Address of Operator P. O. Box 12058, Amarillo, Texas 79101		9. Well No. 1
4. Location of Well EAST LETTER 0 2310 FEET FROM THE East LINE AND 330 FEET FROM THE South LINE, SECTION 23 TOWNSHIP 9S RANGE 36E NMPM.		10. Field and Pool, or Wildcat Crossroads (Siluro Dev.)
15. Elevation (Show whether DF, RT, GR, etc.) 4036' DF		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
 NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work; SEE RULE 1103.

Casing: 9-5/8" 36 & 40# @ 4469'
 5-1/2" 17 & 20# @ 12,174'
 PBTD: 11,492'
 Perforations: 11,447-11,465'
 Packer: Baker Model D @ 11,427'

** if not 100' plug at top of Albo
 * which pipe 100' plug at top of Albo
 100' plug at base of 9 5/8"*

Proposed Plan of Work

1. Run tubing and set cast iron bridge plug @ 11,400'.
2. Spot 20' of cement above bridge plug.
3. Load well bore with mud laden fluid. Pull tubing.
4. Locate free point and shoot off 5-1/2" casing. Pull 5-1/2" casing.
5. Run tubing to 50' below cut off point and spot 50 sack cement plug.
6. Place 10 sack cement plug from 25' to surface with 4" marker imbedded.
7. Return ground to original contour.

*{ 100' plug inside 9 5/8" @ appropriate top of salt
 9.5# mud between plugs*

Anticipated starting date of operations is November 17, 1975.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ed Oswald Jr TITLE Petroleum Engineer DATE October 1, 1975

APPROVED BY John W. Ramsey TITLE Geologist DATE Oct 1, 1975

CONDITIONS OF APPROVAL, IF ANY:

** note above*