

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
NM 058102

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL ☐ GAS WELL ☐ OTHER- Water Injection Well

7. Unit Agreement Name
Flying "M" (SA) Unit

Name of Operator

8. Farm or Lease Name
Tract 10

Coastal Oil & Gas Corporation

Address of Operator

9. Well No.
4

P. O. Box 235, Midland, Texas 79702

Location of Well

10. Field and Pool, or Wildcat
Flying "M" (SA)

UNIT LETTER M 659.2 FEET FROM THE South LINE AND 664 FEET FROM
THE West LINE, SECTION 16 TOWNSHIP 9-S RANGE 33-E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
4384 GR

12. County
Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
OTHER ☐

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

On January 16, 1983, this well was partially plugged and temporarily abandoned (see C-103 dated 8-30-83). P&A proposal as follows:

Well Data: 13-3/8" csg. at 340'. Cmtd with 350 sacks. Cmt. circ.; 8-5/8" csg. at 4599'.
Cmtd. with 450 sacks. Calc. TOC at 1990'.

- GIH with workstring to 4248'. Circ. hole with 9.5 PPG mud.
- POH to 2500' (top of Yates at 2475') and spot 40 sack plug inside 8-5/8" csg. (145' of fill).
- POH with workstring.
- GIH with perf gun and shoot 4 holes at 1980' (T/Salt at 1930') and 4 holes at 390'.
- Pick up retainer and GIH to 1880'. Squeeze below retainer with 75 sacks Class "C". This represents 100' of fillup in the annulus as well as 100' below the retainer to the perfs, plus 60% excess. POH.
- Pick up cement retainer and GIH. Set retainer at 290' and squeeze below with 75 sacks Class "C". This volume represents 100' of fillup in the 8-5/8" casing/13-3/8" casing annulus with 100' of fillup between the retainer and the perfs at 390', plus 20% excess. POH with workstring.
- Back off or cut off 8-5/8" casing at 30-40'.
- Spot 15 sack surface plug inside 13-3/8" casing (20').
- Install P&A marker, clean and restore location.

THIS NOTICE OF ABANDONMENT IS NOTED 24 HOURS AFTER THE PRODUCTION OF OIL OR GAS FROM THIS WELL HAS CEASED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Bobby L. Smith
ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

TITLE Petroleum Engineer

DATE 1-10-85

JAN 15 1985