

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		7. Unit Agreement Name
2. Name of Operator Amoco Production Company		8. Farm or Lease Name Vada-Lee Pruitt "A"
3. Address of Operator P. O. Box 68, Hobbs, New Mexico 88240		9. Well No. 1
4. Location of Well UNIT LETTER <u>0</u> <u>760</u> FEET FROM THE <u>South</u> LINE AND <u>2080</u> FEET FROM THE <u>East</u> LINE, SECTION <u>17</u> TOWNSHIP <u>9-S</u> RANGE <u>34-E</u> NMPM.		10. Field and Pool, or Wildcat Vada Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4289.6'		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:
(Notify NMOCD 24 hr. prior to doing work.) Pull rods and pump, and tubing. Set a cast iron bridge plug at apx. 9700' and cap with 35' of class C neat cement. Spot 50 bbl 10# brine water with 25# gel/bbl. Run free point survey and cut 5-1/2" casing apx. 100' above free point. (Top of cement apx. 7700'). Pull 5-1/2" casing. Spot 25 sacks class C neat cement in/out 5-1/2" casing stub. Spot 210 bbl 10# brine water with 25# gel/bbl. Pull up and spot 50 sacks class C neat cement in/out 8-5/8" casing shoe at 4031'. Spot 55 bbl 10# brine water with 25# gel/bbl. Run free point survey and cut 8-5/8" casing apx. 100' above free point. Pull 8-5/8" casing. Spot 50 sacks class C neat cement in/out 8-5/8" casing stub. Spot 290 bbl. 10# brine water with 25# gel/bbl. Pull up and spot 70 sacks class C neat cement in/out 13-3/8" casing shoe set at 358'. Spot 10# brine water with 25# gel/bbl. Pull up and spot 10 sacks class C neat cement at surface. Cap well and erect PXA marker.

100' PLUG AT TOP OF GLOKIERA

0+5-NMOCD,H 1-HOU, R.E.Ogden,Rm 21.150 1-F.J.Nash, HOU, Rm. 4.206 1-CLF

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Cathy L. Forman TITLE Assist. Admin. Analyst DATE 6-28-83

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT SUPERVISOR DATE JUN 29 1983

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JUN 29 1983

D.C.D.
HOBBS OFFICE