

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
<b>NM 315</b>

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator	8. Farm or Lease Name
<b>Texas Pacific Oil Company, Inc.</b>	<b>J. P. Collier</b>
3. Address of Operator	9. Well No.
<b>P. O. Box 1069, Hobbs, New Mexico 88240</b>	<b>4Y</b>
4. Location of Well	10. Field and Pool, or Wildcat
UNIT LETTER <b>G</b> , <b>1980</b> FEET FROM THE <b>North</b> LINE AND <b>2005</b> FEET FROM	<b>North Bagley Lower Penn</b>
THE <b>East</b> LINE, SECTION <b>10</b> TOWNSHIP <b>11-S</b> RANGE <b>33-E</b> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
<b>4257.7' GR</b>	<b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in and rig up. Install BOP. Pull tubing, pump and packer.
2. Run tubing with packer and squeeze perfs 9862 - 67' with 100 sacks. Test squeeze.
3. Pull tubing and packer. Drill out cement and CIBP at 9950' and 10,050'. Drill cement to 10,120'. Displace with treated water.
4. Reperf with 1 JSPF 10,007 - 10,099' (9 holes). Acidize with 4000 gal. 15% N.R.
5. Swab and test.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original Signed by

SIGNED <b>Sheldon Ward</b>	TITLE <b>Area Superintendent</b>	DATE <b>May 11, 1970</b>
APPROVED BY <b>John W. Runyan</b>	TITLE <b>Geologist</b>	DATE <b>MAY 13 1970</b>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

MAY 12 1970

OIL CONSERVATION COMM.  
WASH., D. C.