

OF COPIES RECEIVED	
DISTRIBUTION	
SAFETY	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-104
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8447-1

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation	8. Farm or Lease Name Lea Full State
3. Address of Operator Box 670, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>N</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1836</u> FEET FROM THE <u>West</u> LINE, SECTION <u>18</u> TOWNSHIP <u>11-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Willcut Inbe Permo Penn.
15. Elevation (Show whether DF, RT, GR, etc.) 4203' GL	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/> Plug and Abandon	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

9920' TD, 9904' PB.

Pull producing equipment. Run cement retainer on 2-3/8" tubing and set retainer at 7950'. Squeeze perforations 9869' to 9875' below retainer with 50 sacks of Class H cement. Spot 50' cement plug on top of retainer. Load hole with abandonment mud. Run free point and cut and recover 5-1/2" casing from approximately 4500'. Spot 100' cement plug in and out of 5-1/2" casing stub. Spot 100' cement plug from 3950' to 4050', across 8-5/8" shoe at 4000'. Run free point and cut and recover 8-5/8" casing from approximately 1500'. Spot 100' cement plug in and out of 8-5/8" casing stub. Spot 100' cement plug from 410' to 310', across 13-3/8" shoe at 360', and 50' cement plug from 50' to surface. Install dry hole marker and clean location.

★ 9.5#

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. B. Borland TITLE Area Production Manager DATE December 20, 1974

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

DEC 2 1974

CIVIL CONSERVATION COMM.
USERS, N. M.