

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator Major, Giebel and Forster	5. State Oil & Gas Lease No. CC 1296-1
3. Address of Operator 1126 Vaughn Building, Midland, Texas 79701	7. Unit Agreement Name
4. Location of Well UNIT LETTER J, 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 36 TOWNSHIP 11-S RANGE 33-E NMPM.	8. Farm or Lease Name Fina-State
15. Elevation (Show whether DF, RT, GR, etc.) 4211 G.L.	9. Well No. 1
	10. Field and Pool, or Wildcat Bagley Penn.
	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	



17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following program is proposed in plugging and abandoning this well:

1. Set a cast iron bridge plug in the 5 1/2" OD 17# casing @ 9600' and dump 20' cement on top of plug.
2. Fill the 5 1/2" casing w/mud.
3. Pull as much 5 1/2" casing as possible.
4. Place a 25 SX cement plug at the top of the 5 1/2" casing stub.
5. Place a 25 SX cement plug @ 5450' (Top of Glorieta @ 5450').
6. Place a 35 SX cement plug @ 3975' (Bottom 8 5/8" casing @ 3975').
7. Pull as much 8 5/8" casing as possible.
8. Place a 25 SX cement plug at the top of the 8 5/8" casing stub.
9. Place a 25 SX cement plug at 390' (Bottom 12 3/4" surface casing @ 390').
10. Place 10 SX cement in top 12 3/4" casing and install marker.
11. Clean up location.

Depending on availability of casing pulling units, it is anticipated this work will be commenced March 26, 1968.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE Engineer	DATE March 12, 1968
APPROVED BY 	TITLE DISTRICT	DATE
CONDITIONS OF APPROVAL, IF ANY:		