

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.
K 3983

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL GAS WELL OTHER
2. Name of Operator
Major, Giebel & Forster
3. Address of Operator
1126 Vaughn Building, Midland, Texas 79701
4. Location of Well
UNIT LETTER B 660 FEET FROM THE North LINE AND 1980 FEET FROM
THE East LINE, SECTION 22 TOWNSHIP 10-S RANGE 33-E NMPM.
7. Unit Agreement Name
8. Farm or Lease Name
Shell State
9. Well No.
2
10. Field and Pool, or Wildcat
Middle Lane Permo Penn
15. Elevation (Show whether DF, RT, GR, etc.)
4208' GL
12. County
Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT
PULL OR ALTER CASING OTHER CASING TEST AND CEMENT JOB
OTHER _____

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The 5 1/2" 17# N-80 casing collapsed during the initial completion of this well and the well has been carried as temporarily abandon. The following program is proposed in plugging and abandoning this well:

1. Set a cast iron bridge plug in the 5 1/2" 17 # N-80 casing @ 9000' and dump 20' cement on top of plug.
2. Fill the 5 1/2" casing w/mud.
3. Pull as much 5 1/2" casing as possible.
4. Place a 25 sack cement plug at the top of the 5 1/2" casing stub.
5. Place a 25 sack cement plug at 5300' (top of Glorieta @ 5308').
6. Place a 35 sack cement plug at 3910' (bottom of 8 5/8" casing @ 3904').
7. Pull as much 8 5/8" casing as possible.
8. Place a 25 sack cement plug at the top of the 8 5/8" casing stub.
9. Place a 25 sack cement plug at 385' (bottom of 12 3/4" casing @ 385').
10. Place 10 sx cement in top of 12 3/4" casing and install marker.
11. Clean up location.

It is anticipated this work will be commenced when approval is received.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED W. A. Sager TITLE Engineer DATE March 29, 1968

APPROVED BY Joe O. Carey TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: