

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K 5702
7. Unit Agreement Name
8. Farm or Lease Name Midwest-State
9. Well No. 1
10. Field and Pool, or Wildcat Middle Lane Permo Penn
12. County Lea

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator Major, Giebel & Forster
3. Address of Operator 1126 Vaughn Building, Midland, Texas 79701
4. Location of Well UNIT LETTER P 660 FEET FROM THE South LINE AND 510 FEET FROM THE East LINE, SECTION 16 TOWNSHIP 10-S RANGE 33-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4194' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following program is proposed in plugging and abandoning this well:

1. Set a cast iron bridge plug in the 5 1/2" OD 17# csg @ 9300' & dump 20' cement on top of plug.
2. Fill the 5 1/2" csg with mud.
3. Pull as much 5 1/2" casing as possible.
4. Place a 25 sx cement plug at the top of the 5 1/2" casing stub.
5. Place a 25 sx cement plug at 5200' (top of Glorieta @ 5194').
6. Place a 35 sx cement plug at 3850' (8 5/8" casing set @ 3820').
7. Pull as much 8 5/8" casing as possible.
8. Place a 25 sx cement plug at the top of the 8 5/8" casing stub.
9. Place a 25 sx cement plug at 380' (12 3/4" surface casing set @ 376').
10. Place 10 sx cement in top 12 3/4" casing & install marker.
11. Clean up location.

Depending on availability of casing pulling units, this work will be commenced April 2, 1968.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Engineer DATE March 15, 1968

APPROVED BY [Signature] TITLE DATE

CONDITIONS OF APPROVAL, IF ANY: