

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SUNDRY NOTICES AND REPORTS ON WELLS <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
		5. State Oil & Gas Lease No. NM-V22
OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>		7. Unit Agreement Name
1. Name of Operator Southern Union Exploration Company		8. Form or Lease Name State "A"
2. Address of Operator Suite 1800 - First International Bldg., Dallas, TX 75270		9. Well No. 2
3. Location of Well UNIT LETTER M 520 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 3 TOWNSHIP 11-S RANGE 33-E N.M.P.M.		10. Field and Pool, or Wildcat N. Bagley, Upper Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4275' Tubing Head		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> OTHER <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set test tank.
2. Rig up workover unit
3. Pull 2 3/8" tubing and 1" tubing.
4. Drill out Baker Model "D" Packer.
5. Run 2 3/8" tubing & swab test.
6. Acidize.
7. Swab test, if commercial run rod string, set pumping unit and tank battery.
8. Put to production.
9. If noncommercial after pump testing, set plug and possibly open another zone at 9400'.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ronald M. Sautz TITLE Drilling & Production Engineer DATE 2/14/80

APPROVED BY Jerry Sautz TITLE Drilling & Production Engineer DATE FEB 25 1980

CONDITIONS OF APPROVAL, IF ANY:

OIL CONSERVATION DIV.

FEB 22 '80

RECEIVED