

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Tom L. Ingram		8. Farm or Lease Name State N
3. Address of Operator POB 1757, Roswell, New Mexico 88201		9. Well No. 1
4. Location of Well UNIT LETTER <u>H</u> <u>2085</u> FEET FROM THE <u>North</u> LINE AND <u>555</u> FEET FROM THE <u>East</u> LINE, SECTION <u>23</u> TOWNSHIP <u>11S</u> RANGE <u>33E</u> NMPM.		10. Field and Pool, or Wildcat Inbe Permo-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4227 GR		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

5/31/73 - 6/4/73

Set cast-iron bridge plug @ 9,010'
Put 35' of cement on top of bridge plug
Cut 5½" casing @ 4490' and pulled
Set 35 sack plug @ 4540' in and out of stub of 5½" casing
Set 50 sack plug @ 4010' in and out of base of 8-5/8" casing
Cut 8-5/8" casing @ 1510', 1360' and 1180'
Pulled 8-5/8" casing from 1180'
Set 50 sack plug from 1230' - 1100' in and out of stub of 8-5/8" casing
Set 75 sack plug @ 403' in and out of base of 13-3/8" casing.
Set 10 sack plug at surface
Set Dry Hole Marker
Mud-laden brine water was used between all plugs
Will notify when surface clean-up is complete

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Tom L. Ingram</u>	TITLE <u>Operator</u>	DATE <u>9/12/73</u>
APPROVED BY <u>John W. Runyan</u>	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		