

COPIES RECEIVED	
TRIBUTION	
FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

NEW MEXICO OIL CONSERVATION COMMISSION

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
348

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. (Drill) Well Name
2. Name of Operator Chaplin Petroleum Company	8. Farm or Lease Name State 17
3. Address of Operator 701 Wilcox Bldg. Midland, TX 79701	9. Well No. ?
4. Location of Well UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>Last</u> LINE, SECTION <u>18</u> TOWNSHIP <u>1-S</u> RANGE <u>34-S</u> NMPM.	10. Field and Pool, or Wildcat Veda Fern
15. Elevation (Show whether DF, RT, GR, etc.) 4214	12. County Deer

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.  
 Data: 13 3/8" Set @ 393' & Circulated  
 8-5/8" Csg. set @ 4104'; 5" Set @ 9915' w/ 500' ex @ TD  
 and 500' ex @ 5403' using Halliburton Stage Cementing Collar  
 (Perf. 9880'-9892')

- Plugging Procedure:
1. Set CI Bridge Plug @ 9800- Dumped cement from 9800'-9765'
  2. Shot Csg @ 3019', 2628, shot & pulled from 2395'
  3. Set Cement plug from 2445' to 2289' thru 2" tubing.
  4. Shot 8-5/8" Csg. @ 1015' & shot & pulled from 891'
  5. Set Cement Plug 1/2 in & out, from 941' to 818' thru 2" tubing
  6. Set Cement Plug 1/2 in & out, from 443' to 338' thru 3" tubing
  7. Set 10' ex out. plug @ surface, installed dry hole marker.

Note: All plugs set with a hole circulated w/ salt water gelled mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.  
 SIGNED \_\_\_\_\_ TITLE Agent DATE 12-9-75

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE JUL 3 1980  
 OIL & GAS INSPECTOR  
 CONDITIONS OF APPROVAL, IF ANY:

**RECEIVED**

**DEC 16 1975**

**OIL CONSERVATION COMM.  
HOBBS, N. M.**