

COPIES RECEIVED		
TRIBUTION		
FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
K-3405	
7. Unit Agreement Name	
8. Farm or Lease Name	
State 18	
9. Well No.	
2	
10. Field and Pool, or Wildcat	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator	3. Address of Operator	4. Location of Well
	Champlin Petroleum Company	701 Wilco Bldg. Midland, TX 79701	UNIT LETTER <u>G</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>18</u> TOWNSHIP <u>10-S</u> RANGE <u>34-E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)			12. County
4214 DF			Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Data: 8 5/8" Csg. set @ 4104', 5 1/2" Set @ 9915' w/500 sx @ T.D.
and 500 sx @ 5403' using Halliburton Stage Cementing Collar
Perfs. 9880'-9892'

Plugging Procedure:

1. Set C.I Bridg Plug @ 9600' above perfs & dump 35' Cmt. on plug
2. Cut off 5 1/2" Csg. @ Top of Cement (Appx 4000) & set 100' cmt. plug in & out of Stub.
3. Cut off 8 5/8" Csg. (Appx 1000") & set 100' cmt plug in & out of stub.
4. Set 100 cmt plug @ base of 13-5/8" csg.
5. Set 10 sx plug @ surface & install Dry hole marker.

Note: All plugs will be set & Hole circulated w/ Salt Gel Mud

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Gene Milford TITLE Agent DATE 12-2-75

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: