

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 87240
District II
811 South First, Artesia, NM 87214
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-025-22582
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
2. Name of Operator Novy Oil & Gas, Inc.		6. State Oil & Gas Lease No. K-6101
3. Address of Operator 125 N. Market St., Suite 1230, Wichita, KS 67202		7. Lease Name or Unit Agreement Name: State 17
4. Well Location Unit Letter <u>K</u> : <u>1980</u> feet from the <u>South</u> line and <u>1980</u> feet from the <u>West</u> line Section <u>17</u> Township <u>10S</u> Range <u>34E</u> NMPM Lea County		8. Well No. 1
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 4235 GR, 4248 RKB		9. Pool name or Wildcat Vada Penn

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- 1 - MIRU workover unit.
- 2 - Pickup swadges - swadge tight casing @ 6292' & 7134'.
- 3 - Set CIBP @ 9908'.
- 4 - Spot acetic acid on bottom. Perf Abo - 9050-40' & 9036-22'.
- 5 - TIH w/tbg. & pkr. Set pkr. @ 9000'.
- 6 - Swab down. Test. Acidize with 2500 gal. 15% NEFE acid.
- 7 - Swab test.
- 8 - POOH w/tbg. & pkr.
- 9 - Run tbg. & rods & put well on pump

Anticipate starting work 2-1-2000

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Frank E. Novy TITLE President DATE 12-28-99

Type or print name Frank E. Novy Telephone No. (316) 265-4651

(This space for State use)

APPROVED BY ORIGINAL SIGNED BY JAMES WILLIAMS TITLE DISTRICT ATTORNEY DATE 12-28-99
Conditions of approval, if any: