

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Atlantic Richfield Company	8. Farm or Lease Name Hanagan State
3. Address of Operator P. O. Box 1978, Roswell, New Mexico 88201	9. Well No. 1
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>17</u> TOWNSHIP <u>10-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat Vada-Penn.
15. Elevation (Show whether DF, RT, GR, etc.) 4243' DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Production from this well has declined to zero oil and a very small amount of gas. No remedial prospects exist. We propose to P & A as follows:

Place DR plug in 415-D at 9887' and cap w/10 sx cement.  
Cut off and recover 5½" casing from free point.  
Place 30 sack cement plug in and out of 5½" stub.  
Place 30 sack cement plug across top of Glorieta @ 5474'.  
Place 30 sack cement plug in and out of 8-5/8" shoe @ 4060'.  
Cut off and recover 8-5/8" casing from free point.  
Place 30 sack cement plug in and out of 8-5/8" stub.  
Place 30 sack cement plug across 13-3/8" shoe @ 399'.  
Place 10 sack cement plug in top of well.  
Erect dry hole marker, clear and level location. 9#/gal salt gel mud will be used to spot all plugs.

→ 30 sack plug at Top & Base of slot if not behind 8 5/8"

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>D.D. Bratches</u>	TITLE <u>Dist. Dirg. Supervisor</u>	DATE <u>11-11-70</u>
APPROVED BY <u>John W. Rangan</u>	TITLE <u>Dist.</u>	DATE <u>NOV 13 1970</u>
CONDITIONS OF APPROVAL, IF ANY:		