

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-1033	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Joseph I. O'Neill, Jr.	8. Farm or Lease Name O'Neill "M" State
3. Address of Operator 410 West Ohio, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>19</u> TOWNSHIP <u>10-S</u> RANGE <u>34-E</u> NMPM.	10. Field and Pool, or Wildcat Vada Pennsylvanian
15. Elevation (Show whether DF, RT, GR, etc.) 4196' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set CIBP @ 9700' (perforations 9911.50 to 9917.50').
- Cut 5-1/2" @ 8000'.
- Spot 50 sx cement plug @ 5-1/2" stub.
- Spot 50 sx cement plug via 5-1/2" csg over Abo shale @ 7700'.
- Spot 50 sx cement plug via 5-1/2" csg over Glorieta @ 5400'.
- Lay down 5-1/2" csg.
- Spot 100 sx cement plug 50' in & out of bottom of 8-5/8" set @ 3972'..
- Cut 8-5/8" @ 3000'.
- Spot 65 sx cement plug @ 8-5/8" stub through 2-3/8" tbq.
- Spot 65 sx in & out of 13-3/8" @ 403'.
- Spot 10 sx in top of 13-3/8" csg.
- Weld on cap & state marker.
- Plugging to be done by Permian Basin Casing Pullers.

*Spot all plugs w/ tubing  
Use mud*

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF DRILLING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Robert Bigard TITLE Drilling Foreman DATE Aug. 21, 1974

APPROVED BY John E. Barney TITLE Drilling Supervisor DATE AUG 26 1974

CONDITIONS OF APPROVAL, IF ANY: