

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

1106BS OFFICE
NEW MEXICO OIL CONSERVATION COMMISSION
JUN 12 3 57 AM '69

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-4601
7. Unit Agreement Name
8. Farm or Lease Name Shell-State
9. Well No. 1
10. Field and Pool, or Wildcat Inbe Permo Penn
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Paul DeCleva
3. Address of Operator 102 Oil Center, Wichita Falls, Texas 76302
4. Location of Well UNIT LETTER B , 660 FEET FROM THE North LINE AND 1830 FEET FROM THE East LINE, SECTION 19 TOWNSHIP 11S RANGE 34E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4202 GR

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CAS NG TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Present Casing and Cement:

12-3/4" @ 317' with 400 sacks, 8-5/8" @ 3774' with 350 sacks, 4-1/2" @ 9965 with 575 sacks.

Proposed Plugging Procedure:

(1) Place 25 sacks @ TD (2) Shoot off 4-1/2" casing at 6000' and attempt to pull or proceed until free point is reached (3) Place 25 sacks cement in and out of stub of 4-1/2" (4) Place 25 sacks at top of Glorietta (5426') if not behind 4-1/2" (5) Place 25 sacks @ top of San Andres (3980') if not behind 4-1/2" (6) Place 25 sacks in base of 8-5/8" casing @ 3774' (7) Shoot off 8-5/8" casing @ 3000' and attempt to pull or proceed until free point is reached (8) Place 25 sacks in and out of stub of 8-5/8" (9) Place 25 sacks at base of salt at + - 2470 if not behind 8-5/8" (10) Place 25 sacks at top of salt if not behind 8-5/8" (11) Place 25 sacks in base of 12-3/4" @ 317' (12) Place 10 sacks in top of surface.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>H. L. McCracken</u>	TITLE <u>H. L. McCracken, Engineer</u>	DATE <u>June 11, 1969</u>
APPROVED BY <u>John W. Runyan</u>	TITLE <u></u>	DATE <u></u>

CONDITIONS OF APPROVAL, IF ANY: