

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPL  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-098-591-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

M.G.F. Oil Corp.

8. FARM OR LEASE NAME

Mallard Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Vada Penn

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA33-660 feet FN & FEL  
TWP 9-S R-34-E

12. COUNTY OR PARISH

13. STATE

Lea County New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS  
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

M.G.F. Oil Corp.

3. ADDRESS OF OPERATOR

1126 Vaughn Bldg. Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface5 miles west of Crossroads, New Mexico  
660 feet F N & F E L Sec.33  
TWP 9-S Range 34-E

14. PERMIT NO.

NM 098-591-A

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4244 G L

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Well Depleted- Proposed Procedure- Plug &amp; abandon as soon as rig available.

Completed 9-10-68 T D 9895

11 3/4" Surface @ 350' Cemented with 350 Sacks

8 5/8" Casing @ 4040' Cemented with 400 Sacks

5 1/2" Casing @ 9895' Cemented with 400 Sacks

Existing Perforations- 9799- 9805

1. Set Cast Iron B P @ 9700' Dump 35' Cement on top.

2. Cut 5 1/2 Casing where free, put 30 sacks cement plug in &amp; out of stub.

\* 3. Spot 30 sack cement plug @ 5426' top of Glor.\*

4. Spot 30 sack cement plug @ 4000' shoe of the 8 5/8.

5. Cut 8 5/8 where free. Spot 50 sack cement plug.

6. Spot 65 sack cement plug @ 350' bottom of surface.

7. 10 sack cement plug @ surface.

8. Brine water to contain 25 sacks Gellmer 5700 BBL  
AMENDMENT: Place additional 35 sack cement plug inside 5 1/2" interval 2000-2100 feet.

Intervals between all plugs to be filled with brine gel mud. Proposed plugging method, as amended, is approved provided 5 1/2" casing can be pulled from below 5500 feet. Otherwise, contact U.S.G.S. for approval of change in plugging procedure.

"IF 5 1/2" CAN BE RECOVERED Below This Point."  
18. I hereby certify that the foregoing is true and correct

SIGNED

W. H. Gault

TITLE

Prod. Foreman

DATE

1-7-74

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED  
AS AMENDED  
JAN 23 1974  
ARTHUR R. BROWN  
DISTRICT ENGINEER

\*See Instructions on Reverse Side